

# Instruction Manual



**SAVE THESE INSTRUCTIONS**—This manual contains important safety and operating instructions for power units.

<b>Product Name:</b>	Modern Gray Resin 3-Urn Pots Outdoor Fountain with LED Lights
<b>SKU #:</b>	WHF728

Thank you for purchasing this LuxenHöme product. This product has been manufactured with the highest standards of safety and quality.

## **PLEASE READ ALL INSTRUCTIONS BEFORE ASSEMBLY.**

Unpack all parts the packaging inside the carton to ensure there are no missing or damaged parts. If any parts are missing or damaged, do not attempt to assemble or use the product. Please save the carton for return and/or storage.

Note: the pump is packaged separately inside the fountain shipping carton. Please check packaging thoroughly.

## **CARTON CONTENTS:**

Description	Quantity
Fountain	1
Pump	1

## **Compatible Pumps for this fountain:**

Pump Model No.
JR600/LED
JB650/LED
YH560/LED
YH-LV130T





**Tools required for assembly:** No tools required for assembly.

## **Assembly Instructions:**

1. Select a flat, level surface for the assembly and final location of your fountain.
2. Insert the water tube located at the small opening at the back of the fountain to the pump. Insert the LED connector into the pump connector, and twist to tighten. Place the pump inside the fountain opening in back.
3. Add clean water into any of the pots in the front of the fountain. The water level should be approximately 30mm lower than the edge of the basin.
4. Connect the pump power cord to a ground fault circuit interrupter (GFCI) outlet and the product will begin to function as intended.
5. Please do not use the electrical plug in wet weather conditions. Please note: On first use, there may be air in the pump. It may take several minutes until all the air escapes.
6. To eliminate the possibility of water damage around your fountain, check for leaks and excessive splashing after the initial setup of your fountain. It is highly recommended that this fountain be placed in an area where it cannot be damaged.
7. Do not leave your fountain running for extended periods of time when no one is present to observe the performance.
8. Check the area around your fountain on a regular basis to ensure that there is no leakage.
9. Please refresh the fountain with water each week to ensure it in good condition.
10. Do not add any harmful chemicals to the water as it may alter the finish.

**SAVE THESE INSTRUCTIONS**—This manual contains important safety and operating instructions for power units.

<b>Product Name:</b>	Modern Gray Resin 3-Urn Pots Outdoor Fountain with LED Lights
<b>SKU #:</b>	WHF728



Note: The above diagram is for illustrative purposes only.

<b>Product Name:</b>	Modern Gray Resin 3-Urn Pots Outdoor Fountain with LED Lights
<b>SKU #:</b>	WHF728

### **MAINTENANCE OF YOUR PUMP:**

- Keep the water clean – clean water will prolong the life of your pump.
- Use a pre-filter on your pump if available.
- Regular cleaning of the pump will be necessary depending on the environment in which it is operated. Clean the pump when it is visibly soiled or when a noticeable drop in performance is detected. **Failure to clean the pump will result in overheating of the pump and the voiding of the warranty!**
- Before cleaning, always disconnect the pump from the power source.
- Disassemble the pump by removing the inlet screen & the impeller housing. Remove the impeller/rotor assembly by gently pulling on the impeller blades. Use a soft cloth or brush to clean the area inside the pump where the impeller/rotor assembly was. Clean the inlet screen, impeller housing & impeller in warm soapy water. Reassemble the pump and inspect it for proper operation.

### **MAINTENANCE OF YOUR FOUNTAIN:**

- Unplug the pump from electric power before servicing, cleaning, or moving.
- Keep water clean - using clean water will reduce mineral deposits and improve water clarity.
- Clean the fountain periodically to prevent mineral deposits and contamination. Use warm soapy water and a stiff brush for heavily stained surfaces. **Do not use harsh chemicals, which will damage the finished surface and void the warranty.**
- Add clean water periodically to ensure the pump is fully submerged.
- Disconnect the power and empty the basin if the fountain is not used for an extended time.
- If installed outdoors and in a frozen area of the country, ensure all water is removed, and the unit is completely dry. **This product is NOT to be operated below 41°F (5°C). Freeze damage may occur.**



### **Special Warnings and Cautions:**

#### **CAUTION:**

- The pump has been evaluated for use with water only.
- Do not use the pump in water exceeding 35°C / 95°F.
- Do not use the pump in flammable liquids.
- Do not use the pump for industrial purposes.
- Do not use the pump in vehicles, ships, aircraft, or swimming pools.
- Do not use the pump in a location where special conditions prevail, such as a corrosive or explosive atmosphere (dust, vapor, or gas).
- Do not let the pump run dry. The pump must be completely submerged for proper operation and cooling.
- Do not lift the pump by its power cord.
- Keep the plug dry. Do not expose the plug to water or steam.
- Before connecting to the power source, ensure the pump is assembled and completely submerged in water.



# Instruction Manual

**SAVE THESE INSTRUCTIONS**—This manual contains important safety and operating instructions for power units.

<b>Product Name:</b>	Modern Gray Resin 3-Urn Pots Outdoor Fountain with LED Lights
<b>SKU #:</b>	WHF728

- Check the water level regularly to ensure the pump is completely submerged during operation. The pump should be fully submerged during operation. Do not add water while operating the product. Always disconnect the pump from the power source before adding water.

## **WARNINGS:**

- To reduce the risk of electric shock, connect only to a properly grounded, grounding-type receptacle.
- To reduce the risk of electric shock, use the pump only for portable, self-contained fountains no larger than 5 feet in any dimension.
- Do not exceed the voltage shown on the pump.
- Always disconnect the pump from the power source before beginning maintenance or work on the pump or fountain.
- Inspect the power cord for damage before installation and maintenance. Replace the entire pump if damage is found.
- For pumps with a 3-prong, grounded type plug, do not remove the grounding pin from the plug on the power cord.

## **TIPS AND TROUBLESHOOTING:**

1. Ensure the pump's flow control switch is set to maximum (+) before operating. Once the flow is established, the pump can be adjusted downward to the desired level.
2. If the pump operates without flow, check to ensure the pump is fully submerged.
3. If the pump operates without flow, check the supply tubing for kinks and correct it.
4. If the pump operates, but there is no flow, and if the pump is submerged and there are no kinks in the supply tubing, lift the pump from the water. Remove supply tubing at the pump outlet and clean tubing inside and out if necessary. Then, reset the pump in water (outlet side up) and re-attach the supply tubing once water begins to flow.