

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

707726
MEDIA TOWER

ITEM:707726

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!













1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

40 MINUTES

PARTS IDENTIFICATION

















A	LEFT SIDE PANEL		1 PC	G	UPPER CROSS PANEL		2 PCS
B	RIGHT SIDE PANEL		1 PC	H	TOP PANEL		1 PC
C	FRONT CROSS BRACE		1 PC	I	UPPER BACK PANEL		3 PCS
D	BOTTOM PANEL		1 PC	J	LOWER BACK PANEL		1 PC
E	ADJUSTABLE SHELF		1 PC	K	DOOR		1 PC
F	LOWER CROSS PANEL		1 PC	L	BACK CROSS BRACE		1 PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:707726

HARDWARE IDENTIFICATION**Z**

NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	9	HANDLE BOLT M5x25mm BLK		2 PCS
2	WOODEN DOWEL ø8x30mm		28 PCS	10	NUT M5		2 PCS
3	CAM BOLT ø7x35.5mm SR		16 PCS	11	HINGE ø35mm SR		2 PCS
4	CAM LOCK ø15x12mm SR		16 PCS	12	HINGE SCREW ø4x15mm SR		8 PCS
5	PLASTIC FEET Ø15mm		4 PCS	13	FIXER		6 PCS
6	PIN FOR ADJUSTABLE SHELF ø4.9x8mm SR		4 PCS	14	FIXER SCREW ø3x19mm SR		6 PCS
7	DOOR CATCH		1 PC	15	SCREW Ø4.5x42mm SR		4 PCS
8	HANDLE BLK		1 PC	16	STICKER ø20mm		3 PCS

Z8,Z9,Z10,Z11 not included in blister packaging.



NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 707726

STEP 1





COASTER
FINE FURNITURE



ITEM: **707726**

STEP 2

COASTER
FINE FURNITURE





Apply glue on all wooden dowels to ensure integrity of the structure.


ITEM: 707726

STEP 3

COASTER
FINE FURNITURE



STEP 4





Apply glue on all wooden dowels to ensure integrity of the structure.



ITEM: **707726**

STEP 5

COASTER
FINE FURNITURE





STEP 6






ITEM: **707726**

STEP 7

COASTER
FINE FURNITURE



STEP 8





ITEM: **707726**


COASTER
FINE FURNITURE

STEP 9

LEFT





RIGHT





ITEM: 707726

STEP 10


COASTER
FINE FURNITURE




RIGHT




HORIZONTAL BY
SCREW A ADJUSTMENT



LATERAL BY
SCREW B ADJUSTMENT








VERTICAL BY
SCREW C ADJUSTMENT





ITEM: **707726**

STEP 11


COASTER
FINE FURNITURE



STEP 12



ITEM: 707726



Note : Dimension tolerance $\pm 5\%$

ANTI-TIPPING INSTALLMENT INSTRUCTIONS

FURNITURE TIPPING RESTRAINT


WARNING

Injury may result from tipping furniture.
This restraint may protect against tipping furniture.
Do not allow children to climb on furniture.
This restraint is not a substitute for proper adult supervision.
Failure to detach this restraint before moving the furniture may result in injury and damage.

This restraint must be screwed to a wood stud on the wall, using the long screw provided.


STEP 1

Secure the bracket to the back top of the unit, using the short screw provided, as shown in the drawing.



STEP 2

Locate the wood stud on the wall, and secure the other bracket, 2 inches below the back of the unit.



STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end, and drag it through, until the slack is removed. Ensure that the strap is securely laced and locked.

