

*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

720223
TV STAND

ITEM:720223

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




















ASSEMBLY TIME

60 MINUTES

MAX TV SIZE : 85"

PARTS IDENTIFICATION












A	LEFT SIDE PANEL		1 PC	J	TOP PANEL		1 PC
B	RIGHT SIDE PANEL		1 PC	K	BACK PANEL		4 PCS
C	LEFT SMALL DIVIDER PANEL		2 PCS	L	GLASS DOOR		4 PCS
D	RIGHT SMALL DIVIDER PANEL		2 PCS	M	DRAWER FRONT PANEL		4 PCS
E	MIDDLE DIVIDER PANEL		1 PC	N	DRAWER BACK PANEL		4 PCS
F	DIVIDER PANEL		2 PCS	O	DRAWER LEFT SIDE PANEL		4 PCS
G	LOWER CROSS BRACE		1 PC	P	DRAWER RIGHT SIDE PANEL		4 PCS
H	BOTTOM PANEL		1 PC	Q	DRAWER BOTTOM PANEL		4 PCS
I	CROSS PANEL		4 PCS				

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:720223

HARDWARE IDENTIFICATION

Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	11	HANDLE		4 PCS
2	WOODEN DOWEL Ø8 x 30mm		35 PCS	12	HANDLE BOLT BLK		4 PCS
3	CAM BOLT Ø7 x 35.5mm SR		40 PCS	13	HINGE Ø35mm SR		8 PCS
4	CAM LOCK Ø15 x 12mm SR		48 PCS	14	HINGE SCREW Ø4x15mm SR		32 PCS
5	SCREW Ø 4.3x35mm SR		32 PCS	15	PLASTIC COVER Ø 52mm		4 PCS
6	PLASTIC FEET Ø15mm		5 PCS	16	BACK PANEL SUPPORT		6 PCS
7	BOLT Ø9.5x55mm SR		6 PCS	17	BACK PANEL SUPPORT SCREW Ø3 x 19mm SR		6 PCS
8	WOODEN DOWEL Ø8 x 50mm		4 PCS	18	CAM BOLT Ø7x63mm SR		4 PCS
9	RAIL L = 300mm BLK		4 PCS	19	STICKER-BK Ø20mm		2 PCS
10	SCREW Ø3x10mm BLK		48 PCS	20	STICKER Ø20mm		6 PCS



Z9, Z11, Z13, Z15 not included in blister packaging.

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **720223**

STEP 1




1



2

x 4



3



x 8



6

x 4


STEP 2



9

CL
CR


x 2



10

x 12

INCORRECT
CORRECT




Apply glue on all wooden dowels to ensure integrity of the structure.


ITEM: 720223

COASTER
FINE FURNITURE

STEP 3




STEP 4




ITEM: **720223**

STEP 5





STEP 6




ITEM: **720223**

STEP 7

COASTER
FINE FURNITURE




1



2



x 4




8

x 2

STEP 8




1



2


x 4



8

x 2

INCORRECT
CORRECT




Apply glue on all wooden dowels to ensure integrity of the structure.




ITEM: **720223**

STEP 9

COASTER
FINE FURNITURE




STEP 10





ITEM: **720223**

STEP 11

COASTER
FINE FURNITURE





STEP 12





ITEM: **720223**

STEP 13

COASTER
FINE FURNITURE




STEP 14




ITEM: 720223

STEP 15




STEP 16




ITEM: 720223

STEP 17





STEP 18








ITEM: **720223**

STEP 19




STEP 20




ITEM: **720223**

COASTER
FINE FURNITURE


STEP 21-1




STEP 21-2




STEP 21-3



STEP 21-4




STEP 21-5




ITEM: **720223**


STEP 22




STEP 23






HORIZONTAL BY
SCREW A ADJUSTMENT



LATERAL BY
SCREW B ADJUSTMENT





VERTICAL BY
SCREW C ADJUSTMENT




ITEM: **720223**

STEP 24

COASTER
FINE FURNITURE






STEP 25






ITEM: **720223**

STEP 26

COASTER
FINE FURNITURE





STEP 27





ITEM: **720223**

STEP 28

COMPLETE



ITEM: 720223



Note : Dimension tolerance $\pm 5\%$

ANTI-TIPPING INSTALLMENT INSTRUCTIONS

FURNITURE TIPPING RESTRAINT


WARNING

Injury may result from tipping furniture.
This restraint may protect against tipping furniture.
Do not allow children to climb on furniture.
This restraint is not a substitute for proper adult supervision.
Failure to detach this restraint before moving the furniture may result in injury and damage.

This restraint must be screwed to a wood stud on the wall, using the long screw provided.


STEP 1

Secure the bracket to the back top of the unit, using the short screw provided, as shown in the drawing.




STEP 2

Locate the wood stud on the wall, and secure the other bracket, 2 inches below the back of the unit.



STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end, and drag it through, until the slack is removed. Ensure that the strap is securely laced and locked.



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

720224
MEDIA TOWER

ITEM:720224

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!




















1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

60 MINUTES









PARTS IDENTIFICATION

A	LEFT SIDE PANEL		1 PC	K	UPPER BACK PANEL		1 PC
B	RIGHT SIDE PANEL		1 PC	L	LOWER BACK PANEL		1 PC
C	LEFT SMALL DIVIDER PANEL		1 PC	M	DRAWER FRONT PANEL		1 PC
D	RIGHT SMALL DIVIDER PANEL		1 PC	N	DRAWER BACK PANEL		1 PC
E	LOWER FRONT TOP BAR		1 PC	O	DRAWER LEFT SIDE PANEL		1 PC
F	BOTTOM PANEL		1 PC	P	DRAWER RIGHT SIDE PANEL		1 PC
G	CROSS PANEL		1 PC	Q	DRAWER BOTTOM PANEL		1 PC
H	MIDDLE PANEL		1 PC	R	UPPER GLASS DOOR		1 PC
I	TOP PANEL		1 PC	S	LOWER GLASS DOOR		1 PC
J	ADJUSTABLE SHELF		2 PCS				

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **720224****HARDWARE IDENTIFICATION**

Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	11	HANDLE		2 PCS
2	WOODEN DOWEL Ø8 x 30mm		23 PCS	12	HANDLE BOLT BLK		2 PCS
3	CAM BOLT Ø7 x 35.5mm SR		22 PCS	13	HINGE Ø35mm SR		4 PCS
4	CAM LOCK Ø15 x 12mm SR		22 PCS	14	HINGE SCREW Ø4x15mm SR		16 PCS
5	SCREW Ø 4.3x35mm SR		12 PCS	15	PLASTIC COVER Ø 52mm		1 PC
6	PLASTIC FEET Ø15mm		4 PCS	16	BACK PANEL SUPPORT		6 PCS
7	PIN FOR ADJUSTABLE SHELF Ø4.9x15mm SR		8 PCS	17	BACK PANEL SUPPORT SCREW Ø3 x 19mm SR		6 PCS
8	DOOR CATCH		4 PCS	18	STICKER-BK Ø20mm		4 PCS
9	RAIL L = 300mm BLK		1 PCS	19	STICKER Ø20mm		2 PCS
10	SCREW Ø3x12mm BLK		12 PCS				


Z9, Z11, Z13, Z15 not included in blister packaging.

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **720224**

STEP 1




STEP 2




ITEM: 720224

COASTER
FINE FURNITURE

STEP 3





STEP 4





ITEM: **720224**

STEP 5

COASTER
FINE FURNITURE




STEP 6




ITEM: **720224**

STEP 7


COASTER
FINE FURNITURE








INCORRECT
CORRECT





Apply glue on all wooden dowels to ensure integrity of the structure.



STEP 8






Section




ITEM: **720224**

STEP 9

COASTER
FINE FURNITURE




STEP 10




ITEM: **720224**

COASTER
FINE FURNITURE

STEP 11






STEP 12




ITEM: **720224**

STEP 13

COASTER
FINE FURNITURE







STEP 14




ITEM: **720224**

STEP 15



COASTER
FINE FURNITURE




STEP 16



R OPEN






L OPEN




ITEM: **720224**

STEP 17

COASTER
FINE FURNITURE




STEP 18




ITEM: **720224**


STEP 19-1




STEP 19-2




STEP 19-3



STEP 19-4




STEP 19-5




ITEM: **720224**


STEP 20




STEP 21








HORIZONTAL BY
SCREW A ADJUSTMENT



LATERAL BY
SCREW B ADJUSTMENT




VERTICAL BY
SCREW C ADJUSTMENT





ITEM: **720224**

COASTER
FINE FURNITURE

STEP 22






STEP 23



ITEM: **720224**

STEP 24

COASTER
FINE FURNITURE






ITEM: **720224**

STEP 25


COMPLETE

COASTER
FINE FURNITURE



ITEM: 720224

COASTER
FINE FURNITURE



Note : Dimension tolerance $\pm 5\%$

ANTI-TIPPING INSTALLMENT INSTRUCTIONS

FURNITURE TIPPING RESTRAINT


WARNING

Injury may result from tipping furniture.
 This restraint may protect against tipping furniture.
 Do not allow children to climb on furniture.
 This restraint is not a substitute for proper adult supervision.
 Failure to detach this restraint before moving the furniture may result in injury and damage.

This restraint must be screwed to a wood stud on the wall, using the long screw provided.


STEP 1

Secure the bracket to the back top of the unit, using the short screw provided, as shown in the drawing.




STEP 2

Locate the wood stud on the wall, and secure the other bracket, 2 inches below the back of the unit.



STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end, and drag it through, until the slack is removed. Ensure that the strap is securely laced and locked.



Note : Dimension tolerance $\pm 5\%$