


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

950432 **TALL ACCENT CABINET**

ITEM:950432

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

















1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

60 MINUTES













PARTS IDENTIFICATION

A	LEFT SIDE PANEL		1 PC	J	MIDDLE PANEL		1 PC
B	RIGHT SIDE PANEL		1 PC	K	LONG DECORATIVE STRIP		1 PC
C	LOWER DIVIDER PANEL		1 PC	L	UPPER CROSS PANEL		1 PC
D	UPPER DIVIDER PANEL		2 PCS	M	TOP PANEL		1 PC
E	LOWER FRONT TOP BAR		2 PCS	N	UPPER BACK PANEL		3 PCS
F	BOTTOM PANEL		1 PC	O	LOWER BACK PANEL		2 PCS
G	ADJUSTABLE SHELF		2 PCS	P	LEFT DOOR		1 PC
H	LOWER CROSS PANEL		1 PC	Q	RIGHT DOOR		1 PC
I	SHORT DECORATIVE STRIP		4 PCS	R	LOWER DOOR		2 PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **950432****HARDWARE IDENTIFICATION****Z**


NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	11	BOLT M4x25mm BLK		8 PCS
2	WOODEN DOWEL Ø8 x 30mm		46 PCS	12	BACK PANEL SUPPORT		6 PCS
3	CAM BOLT Ø7 x 35.5mm SR		30 PCS	13	BACK PANEL SUPPORT SCREW Ø3 x 19mm SR		6 PCS
4	CAM LOCK Ø15 x 12mm SR		30 PCS	14	LED LIGHT		5 PCS
5	SCREW Ø4.5x42mm SR		6 PCS	15	LED FIXING PLATE		10 PCS
6	PLASTIC FEET Ø15mm		4 PCS	16	GLIDES SCREW Ø 3x12mm BLK		10 PCS
7	PIN FOR ADJUSTABLE SHELF Ø4.9 x 15mm SR		8 PCS	17	CABLE HOLDER		1 PC
8	HINGE Ø35mm SR		10 PCS	18	STICKER Ø20mm		5 PCS
9	HINGE SCREW Ø4 x 15mm SR		40 PCS	19	STICKER Ø15mm		2 PCS
10	HANDLE L= 160mm BLK		4 PCS	20	SCREW Ø4.3x35mm SR		11 PCS

Z8, Z10, Z14 not included in blister packaging.**NOTE:**


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **950432**

STEP 1




STEP 2




ITEM: **950432**

COASTER
FINE FURNITURE

STEP 3




STEP 4




ITEM: **950432**

COASTER
FINE FURNITURE

STEP 5




STEP 6




ITEM: **950432**

COASTER
FINE FURNITURE

STEP 7





STEP 8





ITEM: **950432**

STEP 9




STEP 10




ITEM: **950432**

COASTER
FINE FURNITURE

STEP 11





STEP 12




ITEM: **950432**

STEP 13

COASTER
FINE FURNITURE





STEP 14





ITEM: **950432**

STEP 15

COASTER
FINE FURNITURE






STEP 16




ITEM: **950432**

STEP 17

COASTER
FINE FURNITURE




STEP 18




ITEM: **950432**

STEP 19




STEP 20




ITEM: **950432**

STEP 21





STEP 22




ITEM: **950432**

STEP 23




STEP 24





ITEM: **950432**

STEP 25

COASTER
FINE FURNITURE







STEP 26




ITEM: **950432**


STEP 27




STEP 28







HORIZONTAL BY
SCREW A ADJUSTMENT



LATERAL BY
SCREW B ADJUSTMENT







VERTICAL BY
SCREW C ADJUSTMENT



ITEM: **950432**

STEP 29



COASTER
FINE FURNITURE






ITEM: **950432**

STEP 30

COASTER
FINE FURNITURE






STEP 31








ITEM: **950432**

STEP 32

COASTER
FINE FURNITURE







STEP 33











ITEM: **950432**

STEP 34

COASTER
FINE FURNITURE



STEP 35





ITEM: **950432**


STEP 36

COMPLETE

COASTER
FINE FURNITURE



ITEM: **950432**



Note : Dimension tolerance $\pm 5\%$

ANTI-TIPPING INSTALLMENT INSTRUCTIONS

FURNITURE TIPPING RESTRAINT


WARNING

Injury may result from tipping furniture.
This restraint may protect against tipping furniture.
Do not allow children to climb on furniture.
This restraint is not a substitute for proper adult supervision.
Failure to detach this restraint before moving the furniture may result in injury and damage.

This restraint must be screwed to a wood stud on the wall, using the long screw provided.


STEP 1

Secure the bracket to the back top of the unit, using the short screw provided, as shown in the drawing.



STEP 2

Locate the wood stud on the wall, and secure the other bracket, 2 inches below the back of the unit.



STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end, and drag it through, until the slack is removed. Ensure that the strap is securely laced and locked.

