

*ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE*



Fine Furniture for every stage of life

722823
TV STAND

ITEM:722823



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



















ASSEMBLY TIME

60 MINUTES

MAX TV SIZE : 85"












PARTS IDENTIFICATION

A	LEFT SIDE PANEL		1 PC	J	ADJUSTABLE SHELF		2 PCS
B	RIGHT SIDE PANEL		1 PC	K	MIDDLE BACK PANEL		3 PCS
C	LEFT DIVIDER PANEL		1 PC	L	BACK PANEL		2 PCS
D	RIGHT DIVIDER PANEL		1 PC	M	DOOR		2 PCS
E	LEFT DECORATIVE STRIP		1 PC	N	FRONT LEG		2 PCS
F	RIGHT DECORATIVE STRIP		1 PC	O	BACK LEG		2 PCS
G	BOTTOM PANEL		1 PC	P	MIDDLE LEG		1 PC
H	UPPER DECORATIVE STRIP		1 PC	Q	LED FIREPLACE		1 PC
I	TOP PANEL		1 PC				

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **722823****HARDWARE IDENTIFICATION**


Z							
NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	8	DOOR CATCH		2 PCS
2	WOODEN DOWEL Ø8 x 30mm		42 PCS	9	HINGE Ø35mm SR		4 PCS
3	CAM BOLT Ø7 x 35.5mm SR		30 PCS	10	HINGE SCREW Ø4x15mm SR		16 PCS
4	CAM LOCK Ø15 x 12mm SR		30 PCS	11	HANDLE L=120mm BLK		2 PCS
5	BOLT Ø9.5x55mm SR		8 PCS	12	RAIL SCREW Ø 3x15mm BLK		11 PCS
6	PIN FOR ADJUSTABLE SHELF Ø4.9x8mm SR		8 PCS	13	PLASTIC COVER Ø 52mm		2 PCS
7	PLASTIC FEET Ø15m		5 PCS	14	STICKER Ø20mm		5 PCS

Z9, Z11, Z13 not included in blister packaging.**NOTE:**


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **722823**

STEP 1




STEP 2




ITEM: **722823**

STEP 3




STEP 4




ITEM: **722823**

COASTER
FINE FURNITURE

STEP 5





STEP 6





ITEM: **722823**

COASTER
FINE FURNITURE

STEP 7






STEP 8





ITEM: **722823**

COASTER
FINE FURNITURE

STEP 9






STEP 10






ITEM: **722823**

STEP 11





STEP 12





ITEM: **722823**

STEP 13

COASTER
FINE FURNITURE




STEP 14




ITEM: **722823**

STEP 15

COASTER
FINE FURNITURE




STEP 16




ITEM: **722823**

COASTER
FINE FURNITURE

STEP 17




STEP 18







ITEM: **722823**


STEP 19




STEP 20




HORIZONTAL BY
SCREW A ADJUSTMENT



LATERAL BY
SCREW B ADJUSTMENT



VERTICAL BY
SCREW C ADJUSTMENT





ITEM: **722823**





STEP 21

COMPLETE



ITEM: 722823



Note : Dimension tolerance $\pm 5\%$