
























Thank You For Shopping





Component parts supplied















Ref	Dimensions	Visual	Qty
1	26.81x15.67in		1
2	29.17x15.63in		1
3	29.17x15.63in		1
4	15.59x3.31in		2
5	30.24x2.76in		1
6	30.24x2.01in		2
7	30.24x3.19in		1
8	30.24x3.19in		1
9	30.24x3.19in		1
10	30.51x13.54in		1
11	30.51x13.54in		1
12	11.81x4.61in		3

Ref	Dimensions	Visual	Qty
13	11.81x4.61in		3
14	28.35x4.61in		3
15	11.3x2.01in		3
16	28.62x11.77in		3
17	30.04x8.58in		1
18	30.04x8.58in		2


Parts and fittings

Fittings


Please check you have all the fittings listed below with your product.

A  M6x35mm Cam Bolt Screw 47pcs+4pcs extra	B  M15x10mm Cam Lock 47pcs+4pcs extra	C  M6x30mm Wood Dowel 4pcs	D  M3.5x12mm Wood Dowel 24pcs+2pc extra	E  M4x35mm Screw 15pcs+1pc extra	F  Foot pads 4pcs
G  Handle 8pcs	H  Handle 2pcs	I  M8x30mm Wood Dowel 16pcs+1pc extra	J  Hole stickers 12pcs+1pc extra	CL  300mm Cabinet Right Slide 3pcs	CR  300mm Cabinet left Slide Slide 3pcs
DL  300mm Drawer Left slide 3pcs	DR  300mm Drawer Right slide 3pcs				


Ensure the cam lock screws are installed correctly, as indicated by the "check mark" below.








Refer to the illustration below to correctly use the cam lock screws for assembling the panels.




Exploded view









Step 1.





REMARK:



Step 2.




Step 3.




B	
M15x10mm Cam Lock	
4pcs	

Step 4.




Step 5.


F	Foot pads 4pcs
C	M6x30mm Wood Dowel 2pcs
B	M15x10mm Cam Lock 9pcs





Step 6.






Step 7.




H	
Tip proof	
2pcs	
A	
M6x35mm Cam Bolt Screw	
14pcs	


Step 8.





B	
M15x10mm Cam Lock	
6pcs	
I	
M8x30mm Wood Dowel	
8pcs	



Step 9.





B	
M15x10mm Cam Lock	
8pcs	

I	
M8x30mm Wood Dowel	
8pcs	


Step 10.


x3




E	
M4x35mm Screw	
15pcs	


Step 11.




A	
M6x35mm Cam Bolt Screw	
15pcs	


Step 12.





B	
M15x10mm Cam Lock	
15pcs	


J	
Hole stickers	
12pcs	

Step 13.





D

M3.5x12mm Wood Dowel
4pcs


DL

300mm Drawer Left slide
1pcs


DR

300mm Drawer Right slide
1pcs

Step 14.





D

M3.5x12mm Wood Dowel
8pcs

DL

300mm Drawer Left slide
2pcs



DR

300mm Drawer Right slide
2pcs

x2



Step 15.





Step 16. Attach the plastic buckles and screws.





NB: Before tightening the plastic buckles and screws, please ensure the frame is square



Step 17. Drill holes in the wall, insert expansion bolts, and then fix the furniture to the wall with screws.




Step 18.



Wall fixings

Step by step



Important

When drilling into walls always check there are no hidden wires or pipes etc. Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints


1. General Rule; Always use a larger screw and wall plug if you are not sure.
2. Ensure you use the recommended drill bit to match the wall plug and hole size.
3. Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
4. Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure the plug is fitting below the ceramic tile to avoid splitting or cracking.
5. Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of Walls

You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone, wood or plastic board.

1. STANDARD Wall Plug


General wall materials



These come in various sizes and are made from plastic or sometimes wood fibre.

2. GENERAL PURPOSE Wall Plug

Aerated/Breeze block




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, a General Purpose Plug can be used.

3. SHIELD ANCHOR

Wall Plug


Heavy loads



For use with heavier loads such as TV & Hi-fi Speakers and Satellite Dishes etc.


4. CAVITY FIXING

Wall Plug



For use with plaster board partitions or hollow wooden doors.


5. CAVITY FIXING HEAVY DUTY Wall Plug



For use with plaster board partitions or hollow wooden doors.

6. HAMMER FIXING

Wall Plug



For use with walls stuck with plaster board. The hammer fixing allows it to be fixed to the wall rather than the plaster board. Always check the fixing is secure to the retaining wall.

Care and Maintenance

⚠ Safety

Always check the fitting and location to ensure your safety in and around the home.

⚠ Fitting

From time to time check the fitting to ensure the wall plugs or screws do not become loose.

Wall fixings

- This wall fixing is provided for your safety and we recommend that once in position the unit is secured to the wall for extra stability.
- Wall fixings may vary depending on item of furniture purchased.
- Wall fittings are not provided as different wall types require different raw plugs and screws.
- Please ensure that you use fittings that are suitable for your wall type (see next page for a general guide).
- Please ensure that the head of the screws used has a diameter greater than the diameter of the hole on the wall fixing and that the fixing is safe and secure before using.
- When drilling into the walls, always ensure there are no hidden wires or pipes.
- If you are unsure, we recommend you consult a qualified tradesperson.

Wood care advice

Wood care advice

Wood is a natural product and each piece is individual.

As a natural product, wood is affected by temperature and humidity. We recommend that you avoid placing the furniture directly in front of heat sources such as radiators or fires as this can cause cracking or warping over time.

The colour will mellow over time and new items can vary in shade from items that you have already purchased.

Strong direct sunlight can affect the colour dramatically, so try to avoid this as much as possible, we also recommend that any ornaments, coasters and items placed on the product are periodically moved around to allow the colour to mellow evenly.

Always use matts and coasters to protect the surface when placing items on the furniture. This will help to protect the finish from heat, liquids or items that might scratch your furniture.

If items are to be placed on the surface of your furniture and have rubber feet, it is advisable to use mats to prevent marking.

Always lift your furniture into place, avoid dragging it across the floor as this can cause damage to joints.

When placing furniture on a wooden or laminate floor, please ensure that the plastic or felt protectors are securely fitted and in place.

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

From time to time check that there are no loose screws on this unit.

Remove any spills immediately to avoid staining.

Dust regularly with a soft lint free cloth or duster.

The use of abrasive polish or silicon based polishes is not advised as these can affect the polished finish and joints over time.

Uneven floors could give the impression that doors of wall units and wardrobes are out of alignment. Be aware of this and compensate if necessary by adjusting the hinges or packing a corner to level the item. Please refer to the instructions, included with your furniture, and adjust accordingly.

If your furniture becomes stained, scratched, chipped or suffers other damage, we recommend professional help is sought to restore it. Please contact our customer services line for recommended agents.

Always follow fitting instructions carefully and retain them for future use.