

# ASSEMBLY INSTRUCTIONS 30 INCH CABINET



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware. Compare with the parts list to be sure all parts are present.

"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"



- \* Use of power tool to assemble this product will invalidate any claim and damage this product making unsefe!!
- damage this product making unsafe !!!

  \* Please assemble on a clean soft surface to avoid damage.







Tools Required




(Not included)



IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

# PLEASE DO NOT RETURN TO STORE



Please do not return this product to the retailer!!
We are able to assist you in ANY way

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

# **Before Installation**


#### Important - Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.


- . We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- . Please do not over tighten screws or bolts until the assembly is completed.
- . Keep children and animal away from the work area, small parts could choke if swallowed.
- . Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

#### **Cam Lock Assembly Instructions**




#### **Detail View - CABINET**



Identifying the Hardware-Identify the hardware using the illustrations below.


### Part List - N710P186086




# Hardware List - N710P186086


Α	B	С
		( <del>1</del> )
ø6x35mm	ø14.5x9mm	ø10xø5x50mm
Three in one bolts (23pcs)	Three in one lock (23pcs)	Flat head screw (4pcs)
D	E	F
		(Spininininin)
ø12x55mm		ø5/32"x25mm
Plastic stopper (4pcs)	Handle (1pc)	Handle screw (1pc)
G	H	I I
	(†))>	
	ø7xø3.5x15mm	
Damping hinge (2pcs)	Flat head screw (12pcs)	Laminate pad(4pcs)
J	K	L
9////		
ø8x30mm	ø7xø3.5x15mm	
Wood dowel (22pcs)	Round head screw(2pcs)	Steel Pipe (1pc)
M	N	0
		Ø/////
	ø6xø3x12mm	ø6x30mm
Pipe Bracket (2pcs)	Flat head screw (4pcs)	Wood dowel (14pcs)


# Expand hardware (M) into two separate parts















### **STEP: 3**



















**STEP: 5** 






















Draw the spacing between the walls and the No.9, punch holes in the wall, and fix the No.9 to the wall with screws.

Note: Appropriate distance from the top of cabinet to the ground is 74.8".




# **STEP: 16**






# HINGE ADJUSTMENTS



# 1 Sideways / Tilt adjustment


Turn the screw clockwise to move the door further away from the side of the cabinet anticlockwise to move the door closer to the side of the cabinet



# 2 4 Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up anticlockwise to move the door down



# 3 Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

**clockwise** to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

