


TV STAND

USER MANUAL



SAVE THESE INSTRUCTIONS FOR FUTURE USE

PLEASE DO NOT RETURN TO STORE



**Please do not return this product to the retailer!!
We are able to assist you in ANY way**

**If you find that you have any trouble with assembly or
missing or damaged parts please contact the seller.**






Before Installation


Important – Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions

	Diagram A Insert Cam Bolt into hole as shown in diagram A.
	Diagram B Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.
	Diagram C Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.
 Connect the panels together.	
 ARROW SIGN Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.	
 To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. <i>*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</i>	



Ax12



Bx12



Cx24



M6x30

Dx12



M4x40

Ex4




M6x18

Fx8



M3x12

Gx38



M4x12

Hx16




M3x14

Ix4



Jx4



Kx2



M4x35

Lx48




M4x14


Mx4




Nx4



Ox4



Px2



Qx2



Rx4



Sx8





Tx4








Ux2




STEP 1






STEP 2



STEP 3



STEP 4



STEP 5


Bx6




Cx6






M6x30








STEP 6



STEP 7




STEP 8




STEP 9

Gx36





M4x12

Nx4



Ox4




STEP 10

Rx4




Tx4




STEP 11


Jx4



Mx4



Ix4



Fx8




M3x12

Lx16



M4x14





STEP 12

Lx16



M4x14





(For detailed hinge adjustment instructions, please refer to the last page.)

STEP 13

Lx16



M4x14



(For detailed hinge adjustment instructions, please refer to the last page.)


STEP 14

Hx16




M3x14

Gx2





M4x12


Qx2




STEP 15



STEP 16




HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw
clockwise to move the door further away from
the side of the cabinet
anticlockwise to move the door closer to the
side of the cabinet



② ④ Height adjustment

While supporting the weight of the door, turn the
screws
clockwise to move the door up
anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the
cabinet is too small, and the door may not close
fully. Turn the screw
clockwise to decrease the gap between the
door and the cabinet
anticlockwise to increase the gap between the
door and the cabinet

