





## CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

## NOTICE

- \* Please make sure that you have all parts indicated before you begin assembly of this item
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly
- \* This item may require periodic tightening


## Part List and Hardware List

A	Box		1X
B	Leg		4X
H1	Allen bolt	 M6X15mm	16X
H2	Allen key		1X




Model# FOX4279

Product Dimensions: 47-1/4"W X 11-4/5"D X 35-2/5"H



## PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.



Step 1

Attach the Legs(B) to the Box (A),using Allen bolt(H1)

Tighten with Allen key(H2)