# **Assembly Instructions**



### **ASSEMBLY RATING**


The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY OOOODIFFICULT

### Tools Required For Assembly:

Allen Wrench

Phillips Screwdriver






2 PERSONS RECOMMENDED

## **ASSEMBLY & CARE ADVICE**

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY.

PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


#### **BASIC ASSEMBLY TECHNIQUES**




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjusetment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Before you begin, please read Page 2 of "Assembly and Care Advice".


And remember, do not tighten until each step is completed or instructed.


### **Parts List**



Support Rail







Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.

### **Hardware List**



#A x 8pcs Bolt 1/4" X1-3/8"



#B x 8pcs Flat Washer 1/4"



#Cx 8pcs Lock Washer 1/4"



#D x 1pc Allen Wrench



#E x 2pcs L-Bracket



#F x 1pc Cable Tie




#G x 1pc Long Screw



#H x 1pc Short Screw



#J x 1pc Plastic Anchor



- I. Determine exactly where you want to drill a hole and mark the spot(s). Be sure that you hold the drill perpendicular to the wall so that the anchor will sit parallel. You should drill a hole that is approximately the same size as the plastic anchor (#J) itself. Insert anchor.
- II. Insert the cable tie (#F) into the L-brackets (#E). Align one to the pre-drilled hole on the plastic anchor (#J) and the other one to the pre-drilled hole on the chest.
- III. Insert long screw (#G) into the anchor in the wall and secure using the Phillips screwdriver. Then insert the short screw (#H) into the L-bracket to lock it with the chest. Secure using the Phillips screwdriver.



Align the handle to the pre-drilled hole on the front of the drawers and insert the screw on the inner part of the drawer. Secure using the Phillips screwdriver.

