


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.

EASY  DIFFICULT

The image shows a 5-point assembly rating scale. It consists of five circles. The first two circles are solid black, and the next three are white with a black outline. Each circle contains a small white hexagon in the center, representing an Allen wrench head. The word 'EASY' is to the left of the first circle, and 'DIFFICULT' is to the right of the last circle.

Tools Required For Assembly:

Allen Wrench




(Included)


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.




Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List



#1 x 1pc
Right Arm



#2 x 1pc
Back Panel




#3 x 1pc
Seat Panel



#4 x 1pc
Back Cushion1



#5 x 1pc
Back Cushion2



#6 x 1pc
Seat Cushion

Hardware List



#A x 11pcs
Flat Washer



#B x 6pcs
Bolt M6*30



#C x 4pcs
Bolt M6*35



#D x 1pc
Bolt M6*90



#E x 1pc
Nut Cap



#F x 1pc
Allen Wrench M6



#G x 2pcs
Card Buckle




#1

Align seat panel (#3) to the holes of the back panel (#2), then secure by using bolts (#B) with washers (#A).

Align seat panel (#3) to the holes of the back panel (#2), then secure by using bolts (#C) with washers (#A).

#A x 4pcs
#B x 2pcs
#C x 2pcs




#2

Align right arm (#1) to the seat panel (#3), then secure by using bolts (#B) with washers (#A).


Align right arm (#1) to the seat panel (#3), then secure by using bolts (#C) with washers (#A).

#A x 6pcs
#B x 4pcs
#C x 2pcs





#A x 1pc
#D x 1pc
#E x 1pc



Secure back hole by using bolts (#D) with washer (#A). Insert plug (#E) to cover bolt (#D).

