USE AND CARE GUIDE

KBS-52K096

Please scan the below QR code to get the video for easy installation.

Questions or Support?

Email:sofucor_service@163.com
Email:sofucorceilingfan@163.com
www.sofucorfan.com

01 Table of Contents

Safety Information ---- 02
Warranty ---- 03
Ceiling installation ---- 04
Accessory drawing ---- 05
Installation procedure ---- 06
Remote control manual ---- 07
Match code ---- 08
Fans Balance ---- 09
Care and cleaning ---- 10
Trouble shooting ---- 11

02 Safety Information

READ ALL SAFETY INFORMATION AND INSTALLATION INSTRUCTIONS BEFORE YOU BEGIN INSTALLING THE FAN AND SANE INSTRUCTIONS.

Warning:
Kindly turn off the power when connecting cables.

1. To reduce the risk of electric shock, ensure the electricity has been turned off at the circuit breaker or fuse box before you begin.
2. All wiring must be in accordance with the National Electrical Code ANSI/NFPA 70-1999 and local electrical codes. Electrical installation should be performed by a qualified licensed electrician.
3. The outlet box and support structure must be securely mounted and capable of reliably supporting 35 lbs. (15.9 kg) Use only UL Listed outlet boxes marked "Acceptable for Fan Support of 35 lbs. (15.9 kg) or less".
4. The fan must be mounted with a minimum of 7 ft. (2.1 m) clearance from the trailing edge of the blades to the floor.
5. Do not place objects in the path of the blades.
6. To avoid personal injury or damage to the fan and other items, use caution when working around or cleaning the fan
7. Electrical diagrams are for reference only. Light kits that are not packed with the fan must be UI-listed and marked suitable for use with the model fan you are installing. Switches must be UL General Use Switches. Refer to the instructions packaged with the light kits and switches for proper assembly.
8. After making electrical connections, spliced conductors should be turned upward and pushed carefully up into the outlet box. The wires should be spread apart with the grounded conductor and the equipment-grounding conductor on one side of the outlet box.
9. All set screws must be checked and re-tightened where neccessary before installation.

WARNING: To reduce the risk of personal injury, do not bend the blade brackets (also referred to as flanges) during assembly or after installation. Do not insert objects in the path of the blades.

WARNING: To reduce the risk of fire or electric shock, this fan is NOT suitable for use with solid-state speed controls.

WARNING: To avoid possible electrical shock, make sure that the electricity is turned off at the main power box before starting work. If you feel you do not have enough electrical wiring knowledge or experience, contact a licensed electrician.

WARNING: Electrical diagrams are for reference only. Optional use of any light kit shall be UL-listed and marked suitable for use with this fan

WARNING: To reduce the risk of fire, electrical shock or personal injury, ensure that the fan mounting bracket is supported directly from the building structure or the outlet box marked "Acceptable for Fan Support of 35 lbs. (15.9 kg) or less". Use only the screws provided with the outlet box.

03 Warranty

The supplier warrants the fan motor to be free from defects in workmanship and material present at time of shipment from the factory for a lifetime after the date of purchase by the original purchaser. The supplier also warrants that all other fan parts, excluding any glass or acrylic blades, to be free from defects in workmanship and material at the time.

of shipment from the factory for a period of two years after the date of purchase by the original purchaser. We agree to correct such defects without charge or at our option replace with a comparable or superior model if the product is returned.

To obtain warranty service, you must present a copy of the receipt as proof of purchase. All costs of removing and re-installing the product are your responsibility. Damage to any part such as by accident, misuse, improper installation, or by affixing any accessories, is not covered by this warranty.

Because of varying climatic conditions this warranty does not cover any changes in brass finish, including rusting, pitting, corroding, tarnishing, or peeling. Brass finishes of this type give their longest useful life when protected from varying weather conditions. A certain amount of “wobble” is normal and should not be considered a defect.

Servicing performed by unauthorized persons shall render the warranty invalid. There is no other express warranty. Sofucor hereby disclaims any and all warranties, including but not limited to those of merchant ability and fitness for a particular purpose to the extent permitted by law. The duration of any implied warranty which cannot be disclaimed is limited to the time period as specified in the express warranty. Some states do not allow a limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

The retailer shall not be liable for incidental, consequential, or special damages arising out of or in connection with product use or performance except as may otherwise be accorded by law. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion or limitation may not apply to you. This warranty gives specific legal rights, and you may also have other rights which vary from state to state. This warranty supersedes all prior warranties. Shipping costs for any return of product as part of a claim on the warranty must be paid by the customer.

04 Three ceiling installation methods

Concrete Ceiling Mounting Bracket





Hanger for Junction Box Mounting Bracket





Wooden ceiling Mounting Bracket





05 Accessory drawing





06 Installation procedure

1.Place one blade on the motor and align the screw holes

2.Place the reinforcement gasket on the blade

3.Tighten the blade screws

4.Place the other blades one by one and tighten the screws

5.Loosen and remove the 3 silver lamp panel screws pre-locked on the motor(They will be needed later)

6.Put on the lamp panel and feed the wire plugs through the center hole

06 Installation procedure

7.Tighten the 3 silver lamp panel screws

8.Loosen and remove the 3 brass light kit screws pre-locked on the lamp panel(They will be needed later)

9.Connect the light source with the wires from the motor

10.Align the screw holes and tighten the 3 brass light kit screws

11.Turn the fan over

12.Loosen the 2 brass screws pre-locked on the top of the motor

13.Remove 2 screws on the hanger ball

14.Remove the lock pin and the bolt of the base of the downrod

15.Select one downrod and pass all motor wires/light cables through it

16.Insert the bolt

17.Fix the bolt with the lock pin

18.Tighten the 2 screws to prevent fan shaking during operation

19.Put the decorative cover through the downrod

20.Put the canopy cover through the downrod

21.Put the canopy through the downrod

22.Put the hanger ball through the downrod

06 Installation procedure

23.Insert the bolt

24.Fix the green ground wire with screw. Align the screw hole and tighten the screw

25.Insert another screw and tighten the screw

26.Connect the wire from the ceiling fan to the receiver(Blue and White wires)



27.Connect the wire from the ceiling fan to the receiver(Red,White and Black wires)

28.Install the ceiling bracket with four self tapping screws

29.Place the downrod ball into the slot in the ceiling bracket. If the slot doesn't align properly then rotate the ball



30.Use wire connecting nuts to connect the two ground wires(Green)coming from the downrod and hanging bracket

⚠WARNING:
Turn off the electric power during installation and making wire connection



06 Installation procedure

31.Put the receiver into the mounting bracket

32.Lift the cannopy into place so that the screw holes are aligned

33.Wrap keyhole slots around the screws, twist clockwise and tighten 2 screws



34.Lift the canopy cover to the canopy

35.Install the lampshade and rotate it to lock

06 Installation procedure

WARNING: Turn off the electric power during installation and making wire connection.

1. Connect the wire which from ceiling fan into the receiver.
2. Connect the wire from receiver with the wire from house.



07 Remote control manual



①ALL OFF: Turn off the lights and fans at the same time

②Light ON/OFF: Turn on/off the light only
Light color temperature switch: Press twice continuously to switch another color temperature after turing on the light

③6 Speed Settings

④FAN ON/OFF: Turn on/off the fan only

⑤Timer: It will turn off the light and the fan when the time is over

⑥F/R: Changing fan runs direction

⑦Natural Wind

Note: the remote control must match the same code recei

After the reversible button is pressed, the fan slowly slows down to a stop. And then it started to reverse.

08 Fans Balance

if it does not work



1.Turn on the main switch.

2. **Pressing and holding this key for 5 seconds.**

3.The pairing is successful when the LED light flashes



Slide the balancing clip on the trailing edge of any blade, halfway between the holder and tip. Run the fan to check the wobble. If the wobble persists, repeat with each blade, noting which one most reduced the wobble.



Slide the clip in small increments away from the center of that blade. Move the clip, operate the fan, then move it again until you eliminate as much wobble as possible.



Stick the adhesive-backed balancing weight on the top center of the blade directly in line with the balancing clip.Add more weight if needed to get a smooth-running fan.

10 Care and Cleaning

⚠ **WARNING:** Make sure the power is off before cleaning your fan.

□ Because of the fan's natural movement, some connections may become loose. Check the support connections, brackets, and blade attachments twice a year. Make sure they are secure. It is not necessary to remove the fan from the ceiling.

□ Clean your fan periodically to help maintain its new appearance over the years. Do not use water when cleaning, as this could damage the motor, or the wood, or possibly cause an electrical shock. Use only a soft brush or lint-free cloth to avoid scratching the finish. The plating is sealed with a lacquer to minimize discoloration or tarnishing.

□ You can apply a light coat of furniture polish to the wood for additional protection and enhanced beauty. Cover small scratches with a light application of shoe polish.

The motor has permanently-lubricated sealed ball bearings.

11 Trouble shooting

Problem	Solution
The fan will not start.	☐ Check the main and branch circuit fuses or breakers. ☐ Check the line wire connections to the fan and switch wire connections in the switch housing.
The fan is noisy.	☐ Ensure all motor housing screws are snug. ☐ Ensure the screws that attach the fan blade bracket to the motor hub are tight. ☐ Ensure the wire nut connetions are not ratting against each other or the interior wall of the switch housing. ☐ Allow a 24−hour "breaking in" period. Most noises associated with a new fan disappear during this time. ☐ If you are using the Ceiling Fan light kit,ensure the screws securing the glassware are tight.Check that the light ☐ bulbs are also secure. ☐ Ensure the canopy is a short distance from the ceiling.It should not touch the ceiling. ☐ Ensure your outlet box is secure and rubber isolator pads wereused between the mounting plate and outlet box.
The fan wobbles.	☐ Please check and follow the instructions: Chapitre No.13 Fan balance on page 16.

If you have any questions, please contact us. We will help you solve any problem.

Email:sofucor_service@163.com
Email:sofucorceilingfan@163.com
www.sofucorfan.com