ASSEMBLY INSTRUCTION

SQUARE BAR HEIGHT TABLE WITH 18" EXTENSION LEAF

| **A** TABLE TOP	**B** TABLE LEG	**C** ALLEN WRENCH M5	**D** JCBC M8 x 80mm
1 PC	4 PCS	1 PC	8 PCS

| **E** SPRING WASHER M8	**F** FLAT WASHER M8 x 2mm
8 PCS	8 PCS

This Page lists all the contents included in the box . Please take the time to identify the hardware as
well as the individual components to this product . As you unpack and prepare for assembly , place
the contents on a carpeted or padded area to protect them from damage .

1 Place table top(A) upside down on soft surface. Align and fasten all legs(B) to table top(A) using bolt(D), spring washer(E) and flat washer(F) and tighten with Allen wrench(C).

***Do not fully tighten the nut or bolt until all nuts and bolts are attached.

2 Flip table over using two people to lift and flip the table. Unlock the latches underneath table top(A). Pull apart the table top(A) at both ends and take out the center leaf.

3 Push both ends together and make sure pin line up. Close the table top(A) tightly and lock all latches on the underneath of the table.

A

Close

Cleaning & Care
Treat Surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surface with a dry or damp soft cloth. Do not use abrasive cleaners . Hardware may loosen over time. Periodically check that all connections are tight.

ASSEMBLY INSTRUCTION

SPINDLE BACK 24"H COUNTER HEIGHT CHAIR

A CHAIR BACK	B BOX FRAME	C WOODEN SEAT	D FRONT LEG (Left-Right)
1 PC	1 PC	1 PC	2 PCS

E SIDE STRETCHER (Long) (Left-Right)	F FRONT STRETCHER (Short)	G JCBC BOLT M6 x 70MM	H JCBC BOLT M6 x 40MM
2 PCS	1 PC	8 PCS	2 PCS

| I LOCK WASHER M6	J FLAT WASHER M6	K CSK-CB SCREW #8 x 1"	L PAN HEAD SCREW #8 x 1 1/2"
10 PCS	10 PCS	6 PCS	6 PCS

M ALLEN WRENCH M4 x 60MM	N GLUE
1 PC	1 PC

This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpet or padded area to protect them from damage.

1 Put the Chair Back (A), Box Frame (B) upside down on the soft and smooth surface. With assistance attach Box Frame (B) (make sure Arrow sticker is facing upward) onto Chair Back (A). Then insert Jcbc Bolt (G), Lock Washer (I) and Flat Washer (J) into predrilled holes of each corner by using Allen Wrench (M). Insert Jcbc Bolt (H), Lock Washer (I) and Flat Washer (J) into the pre-drilled holes of the middle of Chair Back (A) by using Allen Wrench (M). Do not fully tighten the bolts in this step.


Take the Allen Wrench, and turn the bolts until the legs are secured.
DO NOT TIGHTEN COMPLETELY.
Stop when you feel you are adding force to tighten the bolt.

2 Apply some Glue (N) to the holes of the Chair Back (A) and insert Side Stretcher (E) into the holes of Chair Back (A) with Pan Head Screw (L) by using Screwdriver (not included). Do not fully tighten all screws in this step.

**3** Attach Front Leg (D) assembly to corner of Box Frame (B) along inserting the Front Stretcher (F) onto each hole on Front Leg (D) with applying some Glue (N), then insert Jcbc Bolt (G), Lock Washer (I) and Flat Washer (J) using Allen Wrench (M).


4 Insert Pan Head Screw (L) into the holes of Front Leg (D) and Stretcher (F) by using Screwdriver (not included).

5 Attach Wooden Seat (C) and Box Frame (B) with Csk-Cb Screw (K) by using Screwdriver (not included). Tighten all screws in this step.

6 Turn the assembled chair to the upright position carefully. Make sure the chair is level, and then securely tighten all bolts at this stage. Assembly is now completed.

Stand chair up on an even surface and check that it is balanced. If there is a slight wobble, apply downward pressure in the corner where a leg is uneven. Keeping pressure in that corner, tighten all bolts. If balanced, apply downward pressure evenly in the center and tighten all bolts. Do not over-tighten beyond hole depth.

Helpful Tip: - Instead of applying downward pressure while reaching under to tighten bolts, have someone sit in the chair while you tighten the bolts.

Cleaning & Care

Treat Surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surface with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.