

## **Assembly Instruction**

INSTRUCTION DE MONTAGE MONTAGEANLEITUNG SAMLEVEJLEDNING

MAKE SURE THE LETTERS MATCH BEFORE ASSEMBLING



Make sure to use Gorilla Glue (Not Included) on all wood joints before assembly Code

SST38

**HARDWARE** 

a. 🗀

F-Screw (6 Pcs)

b. @\_\_\_\_\_\_

Screw (4 Pcs)

Tool



Socket Wrench 4m/m Ht

**Total Section** 

4 Section