

Assembly Instruction




ITEM NO : 194S9815-3A SOFA BASE


194S9815-3B SOFA BACK


SOFA

NOTE: Do not use power tools for assembly. Power tools increase the risk of over tightening which leads to splitting or cracking the wood.

COMPONENT LIST ( LEG, PILLOW AND HARDWARE ARE PACKED IN 9815-3A )

| NO | DESCRIPTION   | DRAWING                                                                             | QTY  | NO | DESCRIPTION      | DRAWING                                                                               | QTY   |
|----|---------------|-------------------------------------------------------------------------------------|------|----|------------------|---------------------------------------------------------------------------------------|-------|
| A  | SOFA BASE     |    | 1PC  | H  | BOLT             |    | 8PCS  |
| B  | SOFA BACK     |    | 1PC  | I  | LOCK WASHER      |    | 14PCS |
| C  | SEAT CUSHION  |    | 3PCS | J  | FLAT WASHER      |    | 14PCS |
| D  | PILLOW        |   | 2PCS | K  | ALLEN KEY        |  | 1PC   |
| E  | KIDNEY PILLOW |  | 1PC  | L  | FULL THREAD BOLT |  | 6PCS  |
| F  | LEG           |  | 4PCS | M  | NUT              |  | 6PCS  |
| G  | DOWEL         |  | 4PCS | N  | WRENCH           |  | 1PC   |





### CARE INSTRUCTION FOR POLYESTER:

In order to maintain the original appearance of your polyester furniture, please follow below simple care procedure:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Exposure to sunlight or heating and air conditioning outlets will fade/ damage polyester.
- Wipe gently with a damp soft cloth to remove dust, dirt and any grime build up.



It is recommended to install protective pads under all legs and supports to avoid damage or scratches when placing furniture on a wood floor or other hard surface, and to limit indentation and prevent discoloration if placing on carpet.



Il est recommandé de placer des coussins protecteurs sous tous les pieds et toutes les bases des meubles pour éviter d'endommager ou d'égratigner les planchers en bois ou autres surfaces dures, et pour limiter l'empreinte et empêcher la décoloration quand les meubles reposent sur la moquette.