
ASSEMBLY INSTRUCTIONS



Description : AVA ARM CHAIR

Item No. : CI-13A


ITEM NO.: CI-13A ISSUED DEC 03, 2020

BEFORE ASSEMBLY

Thank you for purchasing this quality product. This product has been designed for easy assembly and constructed for durability. All parts were checked prior to packaging to insure quality. Prior to beginning assembly, however, make sure all parts and hardware are included and free of obvious defect. If a part is missing or defective, please contact the store where purchased. If hardware is missing, or you need help with assembly, please call toll free 888-944-8396.

IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws, bolts until completely assembled.
- Keep all hardware parts out of reach of children.



ITEM NO.: CI-13A Printed in Vietnam

ISSUED DEC 03, 2020

PART LIST

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have the following parts:

NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
A	Chair back	1		В	Seat Frame	1	
С	Chair Seat	1	59	D	Front Leg (L-R)	2	O
Ш	Side Stretcher (L-R)	2		F	Middle Stretcher	1	
G	Arm support (L-R)	2		н	Arm (L-R)	2	

ITEM NO.: CI-13A ISSUED DEC 03, 2020

HARDWARE LIST

When unpacking, please carefully not to discard any parts with the packaging. Before continuing, please make sure you have all of the following hardware:


NO	Description	Qty	Sketch	NO	Description	Qty	Sketch
1	Short Bolt (M6 x 40mm)	3		2	Medium Bolt (M6 x 60mm)	4	
3	Long Bolt (M6 x 80mm)	4		4	Long Bolt (M6 x 100mm)	4	
5	Long Screw (M4 x 50mm)	6	44444	6	Medium Screw (M4 x 35mm)	4	14444
7	Short Screw (M3.5 x15mm)	2	******	8	Lock Washer (Φ6.5 x 11mm)	19	
9	Small Flat Washer (Φ6.5 x 13mm)	4		10	Large Flat Washer (Φ6.5 x 19mm)	15	
11	Hexagon nut (M6 x 10mm)	4		12	Wrench (10 mm)	1	
13	Allen Key (M4 x 30mm x 110mm)	1		14	Wood plug (Φ14.5)	4	

ITEM NO.: CI-13A ISSUED DEC 03, 2020

STEP 1

Attach seat frame (B) to the back (A) with bolts (1) and (3), and washers (8) and (10), as shown below. Tighten with Allen key (13).


Note: DO NOT tighten any of the bolts, until the chair is assembled, then put on a flat level surface to make sure the chair is level and then tighten the bolts.



STEP 2

Attach front legs (D) to the seat frame (B) with bolts (2), and washers (8) and (10) as shown below. Tighten with Allen key (13).


Attach middle stretcher (F) to side stretchers (E) with screws (7). Then attach side stretchers (E) to front and back legs with screws (5) as shown below. Tighten with a screwdriver.



ITEM NO.: CI-13A ISSUED DEC 03, 2020

STEP 3

Insert arm supports (G) into arms (H) as shown below.




STEP 4

Attach arm supports (G) to seat frame with bolts (4), and washers (8) and (9) as shown below. Tighten with the Allen key (13).

Then use nuts (11), and washers (8) and (10) as shown below. Tighten with wrench (12).


Attach arms (H) to the chair back with screws (5). Tighten with a screwdriver.



ITEM NO.: CI-13A ISSUED DEC 03, 2020

STEP 5

Attach the seat (C) to top of the seat frame (B) with screws (6) as shown below. Tighten with a screwdriver. Insert wood plugs (14) over bolts to cover them.



ITEM NO.: CI-13A ISSUED DEC 03, 2020