

Assembly Instruction

Caution: Turn off power before installation. Assemble steps are below:

1. Screw out the threaded bolt by the ⑧ screw driver, and then take out the socket ②, and then install G9 bulb ①;
3. As the figure shown, the socket is taken back for assembling by screwing the threaded bolt by the screwdriver.

