

ASSEMBLY INSTRUCTIONS

MODEL #

CM7124-F/Q

Questions?

GIVE US A CALL: 1-888-980-5122
MON – FRI 8:30AM – 5:30PM (PT)

TOOLS REQUIRED




Allen Wrench

(Included)



**Phillips
Screwdriver**

(Not Included)



**3- People
Recommended**

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



FOA Intro

Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific Time and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



Consumer Hotline
Toll-Free 1-888-980-5122



WEBSITE
www.foagroup.com



Monday to Friday
8:30AM- 5:30PM (PT)



E-MAIL
cs.ec@foagroup.com



foagroup



FurnitureOfAmerica



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!


☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.





Save the instructions and store
any supplied tools for later
maintenance.

After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


FULL BED / QUEEN BED

CM7124-F-Q




PARTS

#1 1pc




Headboard

#2 2pcs




Headboard Leg
- L & R

#3 1pc




Footboard

#4 4pcs




Side Rail - L & R

#5 2pcs



Side Rail
Support Leg

#6 4pcs



Bed Slat


#7 4pcs



Slat Support
29 x 29 x 276 (mm)

HARDWARE

#A 6pcs



JCBB Bolt
M8 x 40 mm

#B 6pcs




Spring Washer
M8

#C 6pcs




Flat Washer
M8

#D 1pc




Allen Key
M5

#E 8pcs



JCBB Bolt
M8 x 16 mm

#F 12pcs



JCBC Bolt
M6 x 40 mm

#G 12pcs




Spring Washer
M6

#H 8pcs




Flat Washer
M6

#I 1pc



Allen Key
M4

#J 8pcs



CSK Screw
M4 x 32 mm

ASSEMBLY INSTRUCTIONS

1

Part #1 x1pc

Part #2 x2pcs


Hardware #A x6pcs

Hardware #B x6pcs

Hardware #C x6pcs

Hardware #D x1pc

Align HB legs (#2R/L) to the headboard (#1), then secure by using bolts (#A) with washers (#B,C).



2

Part #4 x4pcs


Part #5 x2pcs

Hardware #F x8pcs

Hardware #G x8pcs

Hardware #H x8pcs

Hardware #I x1pc




- Tighten the JCBC Bolt (#F) with spring washer (#G) & flat washer (#H) through side rail (#4) to support leg (#5) using allen key (#I).

ASSEMBLY INSTRUCTIONS


3

Part #1 x1pc
Part #3 x1pc
Hardware #E x8pcs



4

Part #1 x1pc
Part #3 x1pc
Part #4 x4pcs
Hardware #D x1pc



ASSEMBLY INSTRUCTIONS

5


Part #6 x4pcs

Part #7 x4pcs

Hardware #F x4pcs

Hardware #G x4pcs

Hardware #I x1pc




- Tighten the JCBC Bolt (#F) with spring washer (#G) through the slat support (#7) using allen key (#I).

NOTE: THE SETUP MUST BE DONE AT THE DECIDED LOCATION FOR THE BED TO OBTAIN PERFECT STABILITY

6

Part #6 x4pcs

Hardware #J x8pcs



- Tighten the CSK Screw (J) through the slat (6) using screw driver.

ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.