

Stiletto installation



1. Mark the position of the hole



2. Drill holes in marked positions with drill bits



3. Drive the expansion screw into the wall



4. Fix the iron frame



5. Screw the nut to fix the mirror



6. The installation is complete