

Installation P2133S Sofa Bed		
CODE	ITEMS	SPE./QUA.
①	sofa	1
②	armrest	2
③	legs	4

Step 1

1. Flip sofa firstly, then install the ③ legs with (C) 8*40 hexagon socket screws at the bottom of the sofa.

Step 2

2. Install ② armrests with (A) 8*30 hexagon socket screws at two sides of sofa.

CODE	PIC	SPE. /QUA
Ⓐ		8*30hexagon socket screws=4
Ⓑ		wrench=1
Ⓒ		8*40 hexagon socket screws=4

Finished

The installation was finished.