


# BDC48VDWM

## Assembly Instructions




# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. A Phillips head screwdriver is required for the assembly of this product .



- V. The provided glue is to secure wood dowels in place . When first inserting dowels , locate the appropriate hole for the dowel , place a small amount of glue in the hole and insert the dowel . Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together , place a small amount of glue on the end of the dowel before attaching parts together . Wipe away excess glue immediately.




## VI HOW THE KNOCK DOWN (KD) ASSEMBLY SYSTEM WORKS


- 1.Screw the Cam Bolt into the pre-drilled hole on the panel. Make sure Cam Bolt goes into the pre-drilled hole on the end of panel for Cam Lock.
- 2.Insert the Cam Lock into the pre-drilled large hole on the panel. Make sure the arrow on the face of Cam Lock points towards Cam Bolt.
- 3.Take a Phillips screwdriver and rotate the Cam Lock clockwise to lock the Cam Bolt.
- 4.Use the sticker to conceal the Cam.





















- VII. Power tools should not be used to assemble this product .




# Parts List
















# Hardware List


|   |   |            |                |         |
|---|---|------------|----------------|---------|
| A |    | Ø8x30mm    | Dowel          | 86 pcs  |
| B |    | Ø6x35mm    | Cam bolt       | 121 pcs |
| C |    | Ø15x11mm   | Large Cam lock | 91 pcs  |
| D |    | Ø30mm      | Cam cover      | 121 pcs |
| E |    |            | Glue tube      | 2 pcs   |
| F |    | Ø5x16mm    | Shelf Pin      | 24 pcs  |
| G |    | 5/32"*12mm | Bolt           | 7 pcs   |
| H |   | Ø4*12mm    | Screw          | 4 pcs   |
| I |  | M 4        | Allen Wrench   | 1 pc    |
| J |  | 1/4"x25mm  | Bolt           | 7 pcs   |
| K |  |            | Plate          | 2 pcs   |
| L |  | Ø6x50mm    | Screw          | 5 pcs   |
| M |  |            | Plastic wedge  | 24 pcs  |
| N |  | Ø3x17mm    | Screw          | 24 pcs  |
| O |  | Ø4x38mm    | Screw          | 32 pcs  |
| P |  | Ø3.5x12mm  | Screw          | 64 pcs  |
| Q |  | 10" Length | Drawer Slider  | 2 sets  |
| R |  |            | Handle         | 7 sets  |



Philips head screwdriver required for assembly  
(not included)


# Hardware List

|    |   |         |                            |        |
|----|---|---------|----------------------------|--------|
| S  |    | Ø15x9mm | Small Cam lock             | 30 pcs |
| T  |    |         | Power Cord W/USB           | 1 pc   |
| U  |    |         | Metal plate                | 2 pcs  |
| V  |    | 12"     | Left Glide Track           | 3 pcs  |
| W  |    | 12"     | Left Glide Runner          | 3 pcs  |
| X  |    | 12"     | Right Glide Track          | 3 pcs  |
| Y  |    | 12"     | Right Glide Runner         | 3 pcs  |
| Z  |   |         | Pulley                     | 2 pcs  |
| AA |  | Ø6x25mm | Bolt                       | 4 pcs  |
| BB |  | 1/4"    | Nut                        | 4 pcs  |
| CC |  |         | Wrench                     | 1 pc   |
| DD |  |         | Tipping Restraint Hardware | 2 sets |
| EE |  |         | Power plug                 | 1 pc   |




Philips head screwdriver required for assembly  
(not included)



## Step 1





## Step 2




## Step 3




## Step 4



## Step 5




## Step 6







## Step 7




## Step 8




## Step 9




## Step 10




## Step 11




## Step 12




## Step 13




## Step 14




## Step 15




## Step 16




## Step 17




## Step 18




## Step 19




## Step 20



## Step 21




## Step 22







## Step 23




## Step 24




## Step 25




## Step 26





## Step 27





## Step 28





## Step 29





## Step 30




## Step 31




## Step 32




# Step 33




# Step 34




## Step 35




## Step 36



## Step 37




## Step 38








## Step 39





## Step 40




## Step 41




## Step 42




## Step 43




## Step 44




## Step 45




## Step 46




## Step 47




## Step 48




## Step 49




## Step 50




## Step 51




## Step 52



## Step 53





## Step 54








## Step 55









## Step 56




## Step 57




## Step 58




## Step 59




## Step 60





## Step 61



## Step 62





## Step 63





## Step 64

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.



Final Assembly