
ASSEMBLY INSTRUCTIONS BATH VANITY-CABINET



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.

Compare with the parts list to be sure all parts are present.

DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED




* Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe !!!
* Please assemble on a clean soft surface to avoid damage.









(Not included)



IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



Please do not return this product to the retailer!! We are able to assist you in ANY way

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.


Before Installation


Important - Please read these instructions fully before starting assembly


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions











Part Lists - N710P195621 18 19 Drawer Bottom Panel - 1pc Drawer Rear Panel - 1pc Sink - 1pc


Hardware Lists - N710P195621		
A	B	C
Ø8*30mm	Ø6*32mm	Ø14.5*9.5mm
Wood dowel (24pcs)	Three in one bolts (14pcs)	Three in one locks (14pcs)
Ø13xØ1/4*40mm	E	Ø13xØ1/4*30mm
Hex-Head bolt (4pcs)	Hinge (2pcs)	Hex-Head bolt (15pcs)
G G	H (\$)	I San Hoad Soft (10pos)
K4mm	Ø6xØ3.5*15mm	
Allen key (1pc)	Flat head screw (12pcs)	The Brass Hinge (L) (1pc)
J		
	Ø5/32*35mm	Ø10x10mm
Handle(2pcs)	Handle screw (2pcs)	Plastic Canopy (4pcs)
	N Ammunum Am	
Ø8xØ4*50mm		Ø6xØ3*12mm
Round head screw (4pcs)	Anti fall Hardware (2sets)	Flat head screw (4pcs)
8	12	13
Leg (4pcs)	Flip Drawer Side Panel (L) - 1pc	Flip Drawer Side Panel (R) - 1pc






















STEP: 11

Install the sink on the cabinet with glue. Let stand for 24 hours






HINGE ADJUSTMENTS



1 Sideways / Tilt adjustment


Turn the screw clockwise to move the door further away from the side of the cabinet anticlockwise to move the door closer to the side of the cabinet



(2) (4) Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up
anticlockwise to move the door down



(3) Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

