


ASSEMBLY INSTRUCTION

36 inch Bathroom Vanity

N710P265934K



PLEASE DO NOT RETURN TO STORE



**Please do not return this product to the retailer!!
We are able to assist you in ANY way**

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.







Before Installation


Important-Please read these instructions fully before starting assembly


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


Cam Lock Assembly Instructions

<p>Diagram A</p> 	<p>Insert Cam Bolt into hole as shown in diagram A.</p>
<p>Diagram B</p> 	<p>Make sure not to insert the Cam Bolt: Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.</p>
<p>Diagram C</p> 	<p>Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C, as this will cause the Cam Lock to be too loose, and not interlock properly.</p>
	<p>Connect the panels together.</p>
	<p>Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.</p>
	<p>To tighten the Cam Lock, turn it clockwise on half a turn with a flat screwdriver. *Do not use an automatic screwdriver as it may bend or break if too much power is imposed.</p>







① x 1




② x 1




③ x 1




④ x 1




⑤ x 1




⑥ x 1





⑦ x 1


















⑧ x 1





⑨ x 1









⑩ x 1

				 M4x14mm	
A x 21	B x21	C x 18	D x 4	E x 61	F x 4
 Ø10x42mm	 M6x60mm				 M4x22mm
G x 2	H x 2	I x 21	J x 2	K x 1	M x 4
		 M4x20mm			
N x 4	Ox 1	Px 4			





Step 1







Step 2







Step 3







Step 4






Step 5









Step 6






Step 7




Step 8









Step 9






Step 10



Step 11




Step 12




Step 13

Install the sink on the cabinet with glue. Let stand for 24 hours


*Silicone glue is not included in the package to comply with safety regulations in certain shipping conditions.



Step 14



HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from the side of the cabinet

anticlockwise to move the door closer to the side of the cabinet




② ④ Height adjustment

While supporting the weight of the door, turn the screws

clockwise to move the door up

anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the cabinet is too small, and the door may not close fully. Turn the screw

clockwise to decrease the gap between the door and the cabinet

anticlockwise to increase the gap between the door and the cabinet

