



# Assembly Instructions

## Hans Wegner Shell Chair

Label	Picture	Qty	Step 1	Step 2	Step 3
A		1	<p>Note: Due to slight gaps between the wooden frames, when installing, all screws should be aligned with the holes on the wooden frame before tightening them one by one</p>		<p>Note: The four M6 * 20 screws on the backrest do not need to be fully tightened, otherwise it is easy to crack wooden board. Tighten the screws to 3-4 turns, and expose half of the screws to hang the back cushion.</p>
B		1			
C		1			
D		1			
E		1	<b>Step 4</b>		<b>Step 5</b>
F		1			
G		1			
H	M6*15mm	6			
I	M6*20mm	7			
J	M6*25mm	15	<p>Use the four holes at the back of the leather plate to line up with the back plate</p>		
K		1	<p>Pls adjust the tightness of screws appropriately before the last screw has been settled.</p>		