

DESK

Assembly Instructions - Please keep for future reference

N704P380671 / N704P380672



Two people are required to assemble and move this model.

Important – Please read these instructions fully before starting assembly

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them
- Keep children and pets away from the installation area, which may cause choking if small parts are swallowed.
- Make sure you have enough space to layout the parts before
- Do not stand or apply weight to the product during assembly. This may cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damage to the unit or floor.
- It's easier for two people to assemble the parts together.
- To reduce the likelihood of damage to your product, make sure your power drill is set to a low torque setting.



Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- Check for loose screws on this unit from time to time.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are correctly tightened.

WARNING

**In order to help prevent overturning –
please follow these instructions**

To help prevent product toppling over please follow the below steps:-

Use the anti tip strap or wall fixing method provided (if applicable).
Do not allow children to climb or hang on the furniture.
Do not open more than one drawer at a time.
Do not place heavy items in the top drawers.
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose.


please note that only the anti tip strap is provided.
You will need to provide wall plugs and screws applicable for your wall type.

Using Camlocks

Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.


1 DO NOT OVER TIGHTEN.



Step 2

Push the male camlock into the entry hole.

2




Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.

3




Step 4

Turn the female camlock clockwise with a screwdriver.


You should feel a click when the camlock is locked in place.

The joint is now secure.





























4




Assembly Instructions




Part List: N704P380671

				
1 PC	1 PC	2 PCS	1 PC	1 PC
				
1 PC	1 PC	1 PC	1 PC	1 PC
				
1 PC	1 PC	1 PC	1 PC	1 PC
				
1 PC	1 PC	4 PCS	2 PCS	2 PCS
				
2 PCS	2 PCS	4 PCS	2 PCS	1 PC
				
6 PCS	6 PCS	6 PCS	6 PCS	1 PC



Part List: N704P380672



Hardware list: N704P380671

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  Male Camlock x 155	B  Female Camlock x 155	C  Dowel x 72
D  Drawer slider 12" x 7	E  4*30mm Screw x 37	F  3*12mm Screw x 58
G  5*40mm Screw x 8	H  Hinge x 2	I  Shelf Support Pin x 24
J  Handle & Fixings x 2	K  Handle & Fixings x 7	L  Pulley x 2
M  Plate x 2	N  4*14mm Screw x 8	O  3*16mm Screw x 24
P  Plasticwedge x 24	Q  Ø20 Sticker x 113	R  Wall Fixing Pack x 2
S  Socket x 1	T  3.5*14mm Screw x 12	U  6*25mm Screw x 16
V  6*40mm Screw x 8	W  10*10mm Screw x 8	 M4 x 1



Phillips screwdriver
(medium & large)


Ruler - Use this ruler to help correctly identify the screws




The screws length is measured from the head to the point (30mm screw shown).

Assembly Instructions

Step 1




Step 2




Assembly Instructions

Step 3




Step 4




Assembly Instructions


Step 5




U x 16

Step 6




Attention:
1. Please locate the holes from the back of part D1.
D1 Back: 


Attention:
1. Please locate the holes from the back of part D1.
D1 Back: 

Assembly Instructions

Step 7





Step 8





Assembly Instructions

Step 9



X2


Step 10





X2

Assembly Instructions

Step 11





Step 12




Assembly Instructions

Step 13




Step 14






Assembly Instructions

Step 15




Step 16





Assembly Instructions

Step 17





Step 18




Assembly Instructions

Step 19




Step 20





Assembly Instructions

Step 21




Step 22




Assembly Instructions

Step 23




Step 24




Assembly Instructions

Step 25




Step 26




Assembly Instructions

Step 28




Step 28




Assembly Instructions

Step 29





Step 30





Assembly Instructions

Step 31




Step 32




Assembly Instructions

Step 33




Step 34




Assembly Instructions

Step 35




Step 36





Assembly Instructions

Step 37





Step 38





Assembly Instructions

Step 39





Step 40




Assembly Instructions

Step 41




Step 42




Assembly Instructions

Step 43



Step 44





Assembly Instructions

Step 45

B



B x 8






Step 46

Q







Q x 60




Assembly Instructions

Step 47




Step 48




X6

Assembly Instructions

Step 49




Step 50






Assembly Instructions

Step 51





Step 52




Assembly Instructions

Step 53





Step 54







Assembly Instructions

Step 55



X2



Step 56



X2


Assembly Instructions

Step 57




X2

Step 58




Assembly Instructions

Step 59




Step 60




Assembly Instructions

Step 61






Step 62





Assembly Instructions

Step 63





Step 64





Assembly Instructions

Step 65




Step 66




Assembly Instructions

Step 67




Step 68




Assembly Instructions

Step 69



Step 70




Assembly Instructions

Step 71




WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.





Assembly Instructions

Step 72




Step 73




Assembly Instructions

Step 74




Step 75




Assembly Instructions

Step 76




Step 77





Assembly Instructions

Step 78






Step 79







Assembly Instructions

Step 80




Step 81






The ways to adjust the door

- Before adjusting the hinge, please check whether the cabinet is skewed.
- If the skew can not be repaired, please remove the anti-tipping device first, then adjust the cabinet to vertical position.
- Please adjust the hinge with the door open.
- Please operate it with more than 2 people, one person holds the door and the other one adjusts the screw.

Components Name




Obvious gaps between doors or Doors don't look closed




※ If the 2 doors are overlap, please turn the "internal & external screw" to the left.

When door is crooked




Please take the following steps to adjust first.


1 Rotate the "font and rear screws to the left



2 Push the door to the cabinet




3 Rotate the "font and rear screws to the right




※ After adjusting the "front and rear screw", the door still does not change, please turn the "internal & external screw" to the right slightly.

When door is leaning




Overlap
Protruding to the underside

1 Turn "internal & external screw" to the left can make the top of the door tilted outward.




Protruding to the underside




1 Turn "internal & external screw" to the left can make the top of the door tilted outward.

1 Turn "internal & external screw" to the left can make the top of the door tilted outward.




When door is higher on top




Have gap


1 Turn "up & down screw" to the left



2 Lower the door's height so that 2 doors are of the same height.



3 Turn "up & down screw" to the right



※ if the door is lower on bottom, please lift up the left door slightly on step 2

A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs (rawl plugs) are supplied with your product, e.g.:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using the incorrect fixings is the responsibility of the installer.



Important: when drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


Hints:

- 1: General rule: always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.5 "Hammer Fixing" wall plug




For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.2 "Plasterboard" wall plug




For use when attaching light loads onto plasterboard partitions.

No.4 "Cavity Fixing - Heavy Duty" wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.6 "Shield Anchor" wall plug - heavy loads



For use with heavier loads such as TV and HiFi speakers and satellite dishes etc.



Care & Maintenance

Safety: always check the fitting and location to ensure your safety in and around the home.

Fitting: from time to time check the fitting to ensure the wall plugs or screws do not become loose.