

Parts and Damage Replacement Procedure

Please inspect your purchase immediately. 1.


- 2. This procedure covers product purchased from an authorized Roundhill Reseller and was received in its originally sealed carton.
- 3. If you find a part missing or damaged, you have a 30-day window in which to order a replacement part from the date on your purchase receipt.
- You have 3 ways to do this. You will need a copy of your purchase receipt. 4.
 - a. By Fax: Fax the parts order form below and along with your receipt to 614-878-7918
 - b. By Email: Email the order form and along with your receipt to: parts@roundhillfurniture.com
 - c. By Mail: Fill out the parts order form below and along with a copy of your receipt send it to Roundhill furniture parts department 5357 Crosswind Dr, Columbus OH 43228
- 5. Once this order is sent in, you will be notified if the part(s) you are requesting can or cannot be shipped within 7-10 business days.

A COPY OF YOUR PURCHASE RECEIPT OR INVOICE MUST BE ATTACHED TO THIS ORDER FORM. NO ORDERS WILL BE PROCESSED WITHOUT PROOF OF PURCHASE.

	NAM	ΛΕ:						
				(No Post Office Boxes)				
	CITY	ſ:	STATE:		ZIP:			
PHONE:			FAX:	_ FAX:				
	EMA	AIL:						
			ON FOR REPLACEMEN					
	 () Damaged /scratched, cracked, broken, crushed, etc. () Mechanical malfunction/ drawer glides, swivel mechanisms, lid stays, etc. () Missing pieces () Unfinished surface () Wrong color () Other 							
		ONE MODEL NU ACE PROVIDED	JMBER IS LISTED ABOV BELOW.	/E, PLEASE SPECIF	Y THE EXACT	MODEL NUMBER OF	YOUR	
	Model	Number		Part Letter (Code	Quantity		



OE0024 ASSEMBLY INSTRUCTIONS





PARTS LIST (1) Top Panel (1 PC) (2) Connection Panel (1 PC) (3) Post (1 PC) (4) Base Panel (1 PC) (5) Foot Pad (3 PCS)




HARDWARE LIST

NO	SKETCH	DESCRIPTION	SIZE	Q'TY
А		BOLT	φ5/16" X 35mm	13 PCS
В	0	FLAT WASHER	φ5/16" X 19 mm	13 PCS
С	0	SPRING WASHER	φ5/16 "	13 PCS
D		WRENCH	5 mm	1 PC




STEP 1:

Attach Connection Panel (2) to Post (3) using three Flat Washers (B), three Spring Washers (C) and three Bolts (A). **TIGHTEN ALL BOLTS USING WRENCH (D).**



STEP 2:


Attach Connection Panel (2) to Top Panel (1) using four Flat Washers (B), four Spring Washers (C) and four Bolts (A). **TIGHTEN ALL BOLTS USING WRENCH (D).**






STEP 3:

Attach Base Panel (4) to Post (1) using three Flat Washers (B), three Spring Washers (C) and three Bolts (A). **TIGHTEN ALL BOLTS USING WRENCH (D).**



STEP 4:

Attach Foot Pads (5) to Base Panel (4) using one Flat Washer (B), one Spring Washer (C) and one Bolt (A) for each Foot Pad (5). **TIGHTEN ALL BOLTS USING WRENCH (D).**



IMPORTANT: MAKE SURE BOLTS ARE SECURELY TIGHTENED BEFORE USING THIS PRODUCT.



