



Combination Lock Instructions

Factory combination is set at 000. You may leave it at this setting, or you may change the setting by following these instructions:

Step 1 – Place the briefcase upright with the handle facing upward. The thin portion of the case should be facing toward your body.

Step 2 – Align the center row of the dials on each side to the factory combination, 000. Press both square buttons outward until both latches release.

Step 3 - Please take a moment to write down your desired 3-digit combination. Both combinations may be similar. However, different combinations will provide extra security.

Step 4 – Setting the Left Dial Combination – Press the left square button again and hold in the outward position. DO NOT RELEASE. From left to right, align the numbers in the center row to the desired new lock combination. Then release the square button.

Step 5 – Setting the Right Dial Combination – Press the right square button again and hold in the outward position. DO NOT RELEASE. From left to right, align the numbers in the center row to the desired new lock combination. Then release the square button.

Step 6 – Close both latches securely and randomly move the dials to scramble the digits.

IMPORTANT: Test your new combination by entering your new 3-digit combination on each dial by lining up the combination on the center row of the dials. Press outward on both latches to open the case.

Thank you and enjoy your purchase.