TOOLS REQUIRED



Allen Wrench

(Included)



Phillips Screwdriver

(Not Included)



2 - People Recommended

ASSEMBLY RATING



EASY → DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



	_	
Are you missing anything?		Check out our Quick Tips!
Double-check all parts, hardware and accessories listed on Page 6 are accounted for.		We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!		Prep Time! Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.






Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS














Table Top

Table leg

Table Shelf

HARDWARE



(#B) 12pcs










Bolt $\phi 5/16$ "X2-1/2" Spring Washer $\phi 5/16$ " Flat Washer $\phi 5/16$ "






Wrench 12mm




1)Prepare 8 bolts assembly by Spring Washer (#B), than flat washer (#C) onto bolts(#A). Align legs (#2) to the holes of the table top (#1). secure by ueing bolts (#A) ,but do not fully tighten.



Hardware (#A) X 4pcs Hardware #B X 4pcs Hardware (#) X 4pcs

> 1)Prepare 4 bolts assembly by Spring Washer (#B),than flat washer (#C) bnto bolts(#A). Secure shelf (#3) by using bolts(#A). Fully tighten all bolts.



ASSEMBLY COMPLETED



Please ensure the furniture rests on even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are ptoperly tightened and secured

Keep this handy!


Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!


To avaoid damage to producet please always LIFT the product when transporting at adjusting the placement.



- · Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS





















Chair back

Seat

Front leg


Side stretcher L/R

Front stretcher

HARDWARE

















Bolt \$\phi 1/4"X3"

Bolt Ø1/4"X2-1/2"

Bolt \$\phi 1/4" X1-1/2" Spring Washer \$\phi 1/4"











Flat Washer Ø1/4" Allen Wrench M4





bolts (#C) Do not fully tighten bolts(#C).

1


Part #1 X 1pc

Part #3 X 1pc

Hardware #C X 2pcs

Hardware #D X 2pcs

Hardware (#E) X 2pcs




Prepare 2 bolts assembly by Spring Washer (#D),than flat washer (#E) onto bolts(#C).Align seat frame(#3) to the chair back(#1).then secure by ueing

2

Prepare 4 bolts assembly by Spring Washer (#D),than flat washer (#E) onto bolts(#A). Secure cornerholes holes of seat frame(#3)to chair back(#1) by ueing bolts (#A). Fully tighten bolts(#A.C).

Hardware#A X 4pcs
Hardware#D X 4pcs


Hardware #E X 4pcs



3

Prepare 4 bolts assembly by Spring Washer (#D),than flat washer (#E) onto bolts(#B).Align front legs(#4) to the holes of the chair frame(#3).Secure by using bolts(#B)

Part #4 X 2pcs
Hardware #B X 4pcs
Hardware #D X 4pcs
Hardware #E X 4pcs




4

Part #4 X 2pcs

Part #5 X 1pc

Hardware (G) X 6pcs

Prepare 6 scerews(#G) assemble the seat cushion(#3) than tighten the screws



ASSEMBLY COMPLETED



Please ensure the furniture rests on even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are ptoperly tightened and secured.

 ✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avaoid damage to producet please always LIFT the product when transporting at adjusting the placement.