

## LIBERTY FURNITURE


## **ASSEMBLY INSTRUCTION**

ITEM#: 422-OT1011

**DESCRIPTION**: LIFT TOP COOKTAIL TABLE

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below.

## **COMPLETED:**



PA	PARTS LIST					
NO	DRAWING	DESCRIPTION	Q'TY			
1		Table Top	1			
2		Side Frame	2			
3		Bottom Shelf	1			

## **HARDWARE LIST**

NO	DRAWING	DESCRIPTION	Q'TY
Α		Bolt Ø1/4-20*38(L)	14
В	0	Flat Washer Ø1/4"*Ø16*2mm	14
C	0	Spring Washer Ø1/4"*Ø13mm	14
D	7	Allen key M4	1
Е	0	Plastic Cap	8

