

















ITEM#: 412-HO111

DESCRIPTION: WRITING DESK

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small Hardware which may have come loose inside the carton during shipment. Identify and count all Hardware and compare with the Hardware List Below.


Parts List			
No.	Description	Drawing	Qty.
①	Desk Top		1 Pc
②	Top Stretcher		1 Pc
③	Bottom Panel		1 Pc
④	Side Panel		2 Pcs

Hardware List (Pack inside Writing Desk)				
No.	Description	Drawing	Size	Qty.
Ⓐ	Hanger Bolt		Ø 5/16"-18 x 3*1/2 "	4 Pcs
Ⓑ	Hanger Nut		Ø 5/16"	4 Pcs
Ⓒ	Half Round Washer		Ø 5/16" x 28 x14	4 Pcs
Ⓓ	Wrench		12 mm	1 Pc
Ⓔ	Bolt		Ø 1/4"-20 x 3*1/2 "	4 Pcs
Ⓕ	Spring Washer		Ø 1/4"	4 Pcs
Ⓖ	Flat Washer		Ø 1/4" x 13mm x 2mm	4 Pcs
Ⓗ	Allen Key		M4	1 Pc
Ⓘ	Bolt		Ø 5/16"-18 x 1*3/4 "	8 Pcs
Ⓙ	Spring Washer		Ø 5/16"	8 Pcs
Ⓚ	Flat Washer		Ø 5/16" x 22mm x 2mm	8 Pcs
Ⓟ	Plug			4 Pcs

ITEM#: 412-HO111


DESCRIPTION: WRITING DESK

STEP 1




NOTE: Do not fully tighten Bolts until the assembly is completed.


STEP 2




STEP 3



STEP 4



DRAWER REMOVAL GUIDANCE



To remove drawer, simultaneously pull tab up on one side and push down on the other and remove drawer.

