



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

650355
Glider Loveseat

ITEM: **650355**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES


PARTS IDENTIFICATION

A LEFT BACK




1PC

B RIGHT BACK




1PC

C CONSOLE BACK



1PC

D BASE




1PC

E LEFT EAR



1PC

F RIGHT EAR




1PC

ITEM: **650355**




ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2




STEP 3




STEP 4 **COMPLETE**



ITEM: **650355**



Inner Size of Drawer : 10.00"W x 12.75"D x 6.25"H x 0.50"T



Note: Dimension tolerance $\pm 5\%$