












ASSEMBLY INSTRUCTIONS


BENCH WITH CURVED ARMS

A Back Rest  1 pc	B Seat  1 pc	C Right Leg  1 pc	D Left Leg  1 pc
E Bolt 1/4 " x 2"  9 pcs	F Bolt 1/4" x 1 1/2"  4 pcs	G Lock Washer 1/4" x 10mm  9 pcs	H Flat Washer 1/4" x 19mm  9 pcs
I Trim Ø14.5 x 8mmH  4 pcs	J Allen Wrench 4mm  1 pc		




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

- 1** Place the Back Rest (A) on a smooth carpeted surface. Attach the Seat (B) to the Back Rest (A) by using Bolt (E), Lock Washer (G) and Flat Washer (H) with the Allen Wrench (J).




- 2**
- (i) Attach the Leg (C & D) to the Back Rest (A) by using Bolt (F) with the Allen Wrench (J).
 - (ii) Attach the Seat (B) to the Leg (C & D) by using Bolt (E), Lock Washer (G) and Flat Washer (H) with the Allen Wrench (J).



3

Insert the Trim (I) into the Leg (C & D).



Cleaning & Care

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.