


## **ASSEMBLY INSTRUCTION**






This page lists all the contants included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


Turn The Server (A) upside down on a protective surface such as carpet or other soft material. Remove the square block which screw at the four corner of Server Top. Turn the screw anti-clockwise. See diagram below.




Insert Left & Right Center Vertical Panel (D) following the picture below and tighten it with Flat Washer (K), Spring Washer (L) and JCBC Bolt (J) using Allen Key (N).




Push in the Back Panel (G). Then insert V:ooden Dowel (O) at the bottom of both Center Vertical Panel (D).




Aligh the dowel holes on the Shelf (B) to the dowel at the Center Vertical Panel (D), then tighten it with Flat Washer (K), Spring Washer (L) and JCBC Bolt (J) using Allen Key (N).



Place the Leg (C) to the corner of Apron and tighten it with Flat Washer (K), Spring Washer (L) and Hex Bolt (I) using Wrench(M). Repeat the same to the other Legs. Insert and turn the Hanger Bolt of Bottom Leg Support (H) to the holes at the center of Shelf (B). Adjust the leveler to level the unit.



Turn the Server on it's position. Assemble the Wine Rack (Vertical) (E) to the Wine Rack (Horizontal) (F), following the picture and insert the complete Wine Rack assembly to the Server.



## **CLEANING & CARE**

Treat surface with care. Surface is resistant to scratches but is not scratches resistant. Clean surface with a dry or dampsoft cloth. Do not use abrasive cleaners. Hardware may loosen overtime. Priodically check that all connections are tight.