













**PC013TA - PC014TA  
PC015GY - PC016GY**

# Assembly Instructions

| PARTS |   |                       |      |
|-------|---|-----------------------|------|
| 1     |  | SEAT                  | 1PC  |
| 2     |  | SIDE STRETCHER        | 2PCS |
| 3     |  | FRONT, BACK STRETCHER | 2PCS |
| 4     |  | LEGS                  | 4PCS |

| HARDWARE LIST |  |                    |      |
|---------------|--|--------------------|------|
| A             |  | Ø1/4" x 2-1/8"     | 8PCS |
| B             |   | Ø1/4"              | 8PCS |
| C             |   | Ø1/4" x 19 x 1.5mm | 8PCS |
| D             |  | 4mm                | 1PC  |
| E             |  | #8 x 45mm          | 8PCS |



Do not tighten screws until completely assembled