





Assembly Instructions

Caution : You must read this before you proceed





RECLINER CHAIR



Parts List


Label	Picture	Description	QTY
A		Chair Backrest	1
B		Chair Base Body	1
C		Leg	4

Hardware

Label	Picture	Description	QTY
①		Plastic Washer	7
②		Silicon Washer	4
③		Screw(M4*40MM)	5
④		Screwdriver	1

Assembly Preparation

Before
Beginning
Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

OVERVIEW




This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the chair parts, the above picture is to help you put the various chair parts into perspective. Please read through the instructions to familiarise yourself with the parts and steps before assembly.

Step 1



Place the Chair Base Body(B) on a clean, non-marring surface, as shown. Take out the 4 legs and Hardware from inner box, as above picture shown on.


Step 2



Position the Chair Base Body(B) as shown above. Install the Leg(C) into the bottom of the Chair Base Body(B) by placing one Plastic Washer(①) and one Silicon Washer(②) onto the threaded stem, then, **tighten by turning the Leg Clockwise. DO NOT OVER TIGHT**. Repeat the same step to install the remaining Legs(C). Take care of the shape of the Legs and ensure they are in the correct position.


Note: The use of the Plastic Washer(①) are **OPTIONAL** and are especially useful to help alleviate slight wobbleness. Some legs may need more than one gasket whilst some legs may not need any.

Step 3




Align the mounting positions of the Leg(C) onto Chair Base Body(B) and attach them with Screw(④) using Screwdrive(③), as shown above. Repeat the same step to install remaining Legs(C).

Step 4



With assistance from your adult partner, hold up the fully assembled Chair Backrest (A) stand behind the Chair Base Body(B).
Insert the small Metal Arms on the sides of the Chair Backrest(A) into the prefabricated slide lock gadget on the Chair Base Body(B) as shown above.
Firmly but gently, push the Chair Backrest(A) downwards until the Backrest(A) is fully slotted and locked into position.

Step 5



Your Recliner Chair is ready for use.

Caution :This Chair can only be used on a flat, level surface.


User Instructions.

Recliner Chair

Please read the Instruction Manual below carefully before use.

This is a Recliner Chair. At anytime in a reclined seat position or in the upright position. You may enjoy the rocking motion by using your body weight in a back-front rocking motion.


Supervise children, when in use of this Recliner.



Do not allow children to play on the chair.
Always leave the chair in an upright and closed position after use.
Keep hands and feet clear of the footrest mechanism and ANY gaps.
Only the occupant should operate the Chair.


To get into a reclined posture - To Recline backrest

Sit into the seat.
Place your feet apart .
Place your left and right arm onto the armrest.
Synchronise a backward push with your arms.
Use your body weight and push backwards into the seat into a fully reclined position.



To get out of chair - move Seatback into Upright Position

Tilt your body weight slightly forward and upwards.
The seat back will come up to an upright position.
Where necessary, use either your arms help lift- push yourself out of the seat.



Care & Maintenance

-  Do not put hot items directly on furniture surface
-  Do not clean furniture with harsh cleansers or polish.
-  Do not place furniture under direct sunlight.
-  Do not place furniture near heating or cooling vents.
-  Do not write on furniture without a padded barrier to protect the surface.
-  Do not place furniture outside . For indoor use only .
-  Not for commercial use. For residential use only .
-  Stains may be removed with mild soap solution and damp cloth.
-  Children should not climb or jump on the furniture.

 Dust and pick-up spills using a clean, non-colored, lint-free cloth .