


Assembly Instructions

Chair

Caution: You must read this before you proceed

Please look underneath the seat frame for hardware packs.








Caution: This Chair is NOT a TOY





Keep your child/children at bay during the assembly process.

Whenever moving/lifting the Chair and to prevent damage to the Chair, two adults are needed to execute these actions.

Part List

Label	Picture	Description	QTY
A		Seat Frame	1
B		Upper Leg Panel	1
C		Lower Leg Panel	1
D		Seat Cushion	1
E		Back Cushion	1

Hardware

Label	Picture	Description	QTY
①		Bolt (M6x65mm)	5
②		Screw (M4x30mm)	5
③		Allen Key 4	2
④		Screw Driver (not provided)	1

Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1



Unpack and place all parts on a clean, non-marring surface.

Step 2




Place the Seat Frame (A) facedown on a clean, non-marring surface.
Attach the Upper Leg Panel (B) to the Seat Frame (A) using Bolts (①) and the Allen Key(③) as shown above.

Do not fully tighten the Bolts.


Caution: Please don't place your hands between the gaps to avoid injury.

Step 3




First, insert the Lower Leg Panel (C) into the Upper Leg Panel (B)
Then, attach the Lower Leg Panel (C) to the Seat Frame (A) using Bolts (①) and the Allen Key (③) as shown above
Do not fully tighten the Bolts.

Step 4



Secure the Upper Leg Panel (B) and the Lower Leg Panel (C) into Seat Frame(A) by using Screws (②) and a Screwdriver (not provided) (④) as shown above.
Do not fully tighten the Screws.

Step 5



Place the Chair onto a flat, level surface.

Then EXERT pressure floorward onto the Chair with both hands.

This pressure will help the Chair reach full alignment at all joints.


In a sequential manner, gradually tighten all Bolts and screws at all joints until evenly secured.

Inspect the Chair and make sure all parts are adequately connected.

Adjust the Levelers until the Chair is level with the ground.



















To adjust the Levelers, get assistance from an adult partner to lean and hold the Chair while you are working.

Step 6



Place the Seat Cushion (D) and the Back Cushion (E) onto the Seat Frame (A).
With the help of your adult partner, turn the chair over and Tie the velcro straps on the Seat Cushion (D) to the Seat Frame (A) as shown above
Inspect it and make sure all parts are adequately connected.
Ensure all screws, bolts are fully locked into position and secured.
Then again with the help of your adult partner, turn the Chair right side up.
The Chair is ready to be used.
Caution: This Chair can only be used on a flat, level surface.

Care & Maintenance

-   ● Do not put hot items directly on furniture surface
 -   ● Do not clean furniture with harsh cleansers or polish.
 -   ● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
 -   ● Children should not climb or jump on the furniture.
 -   ● Do not write on furniture without a padded barrier to protect the surface.
 -   ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
 -   ● Not for commercial use. For residential use only .
 -   ● Stains may be removed with mild soap solution and damp cloth.
-
-   ● Dust and pick-up spills using a clean, non-colored, lint-free cloth .