

ASSEMBLY INSTRUCTION

ITEM#: 824-EC68 / TV66 / EL78 / ER78


DESCRIPTION : ENTERTAINMENT HUTCH

ENTERTAINMENT TV STAND

LEFT PIER RIGHT PIER

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small Hardware which may have come loose inside the carton during shipment. Identify and count all Hardware and compare with

the Hardware List Below.



•				
Hutch Parts List				
1	2			
Light Bridge : 1pc	Adjustable Shelf : 1pc			
3	4			
LSF Frame : 1pc	RSF Frame : 1pc			
(5)	6			
Top Back Rail : 1pc	Bottom Back Rail: 1pc			
7	8			
Top Back Rail Support : 1pc	Bottom Back Rail Support :1pc			
9	0			
Side Back Panel Frame :2 pcs	Center Back Panel Frame :1pc			

		Side	Side Back Panel Frame :2 pcs Center Back Panel Frame :1pc			
Parts L	_ist		Assembly Hardware Pack			
Description			10			
Glass Shelf : 2pcs Glass Shelf : 2pcs	No.	Description	Hardware	Qty.		
	A	JCBC Screw Ø1/4" x 40mm	() (()()()()()()()()()()()()()()()()()(22 pcs		
	B	Spring Washer Ø1/4"	0	22 pcs		
	f:2pcs C	Flat Washer Ø1/4" x 13mm	0	6 pcs		
		(D)	Allen Key M4		1 pc	
Left Pier : 1pc Right Pier : 1pc	E	Wood Cap	Θ	6 pcs		
	c F	Flat Washer Ø1/4" x 19mm	0	16 pcs		
		G	Hanger Bolt Ø5/16" x 89mm		6 pcs	
		Θ	Round Half Washer Ø5/16"	0	6 pcs	
		K	Hange nut Ø5/16"	3	6 pcs	
			Wrench	<u></u>	1 pc	
	J	PH Screw M4 x 32mm	<u>0</u>	7 pcs		
	M	CBS Screw M4 x 20mm	(g)	4 pcs		
T		N	CBS Screw M3.5 x 12mm	(g)22222220>	4 pcs	
	0	Shelf Pin	Ĵ	4 pcs		
TV Stand : 1pc		(P)	Tipping Restraint		1 Set	




ASSEMBLY INSTRUCTION

DESCRIPTION: ENTERTAINMENT HUTCH ITEM#: 824-EC68 / TV66 / EL78 / ER78

ENTERTAINMENT TV STAND

LEFT PIER RIGHT PIER






ASSEMBLY INSTRUCTION

ITEM#: 824-EC68 / TV66 / EL78 / ER78

DESCRIPTION : ENTERTAINMENT HUTCH ENTERTAINMENT TV STAND

LEFT PIER RIGHT PIER







ASSEMBLY INSTRUCTION

ITEM#: 824-EC68 / TV66 / EL78 / ER78

DESCRIPTION : ENTERTAINMENT HUTCH
ENTERTAINMENT TV STAND





PAGE 4 OF 4