















ITEM#: 652-HO107


DESCRIPTION : WRITING DESK

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small Hardware which may have come loose inside the carton during shipment. Identify and count all Hardware and compare with the Hardware List Below.


Parts List			
No.	Description		Qty.
①	Table Top		1 Pc
②	Top Stretcher		1 Pc
③	Bottom Stretcher		1 Pc
④	Leg Frame		2 Pcs

⑤			
No.	Description		Qty.
Ⓐ	Hanger Bolt Ø5/16" x 89mm		4 Pcs
Ⓑ	Hanger Nut Ø5/16"		4 Pcs
Ⓒ	Half Round Washer		4 Pcs
Ⓓ	Wrench 12mm		1 Pc
Ⓔ	JCBC Screw Ø5/16" x 38mm		8 Pcs
Ⓕ	Spring Washer Ø5/16"		8 Pcs
Ⓖ	Flat Washer Ø5/16" x 19mm		8 Pcs
Ⓗ	Allen Key M4		1 Pc
Ⓚ	JCBC Screw Ø1/4" x 89 mm		4 Pcs
Ⓘ	Spring Washer Ø1/4"		4 Pcs
Ⓙ	Flat Washer Ø1/4" x 13mm		4 Pcs
Ⓜ	Cap nut		4 Pcs


### STEP 1



### STEP 2




### STEP 3



### STEP 4

Adjustable Leveler

### DRAWER REMOVAL GUIDANCE



To remove drawer, simultaneously pull  
tab up on one side and push down on  
the other and remove drawer.

