


ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



**Phillips
Screwdriver**

(Not Included)



**2 - Persons
Recommended**

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!


☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.



Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.




Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Save the instructions and store
any supplied tools for later
maintenance.

Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


CAM LOCK FASTENER

ASSEMBLY

INSTRUCTIONS

Note :


Every cam lock bolt must have a cam lock connector in order to fasten the parts together.




cam bolt



cam lock




screwdriver




1

Screw the cam bolt into panel.




2

Insert the cam bolt into the bolt hole of joint panel.



3

Align the cam lock with its side opening (or arrow) pointing to cam bolt.




4

Turn the cam lock clockwise gently until it will not turn any more.


BAKER'S RACK




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS



HARDWARE




ACCESSORIES




GET READY

Please group boards as below.


A 1PC




D 1PC




E 1PC




F 1PC




G 1PC




B 1PC




H 1PC




I 1PC




J 1PC




K 1PC




C 1PC




S 1PC




T 1PC



U 2PCS




V 1PC




Body

L 4PCS




Shelf


M 1PC




N 1PC




O 1PC




P 1PC



Q 1PC



R 1PC






Drawer




ASSEMBLY INSTRUCTIONS

1

Hardware ① x8PCS
Hardware ③ x5PCS



Finished Side








ASSEMBLY INSTRUCTIONS

2

Hardware ① x4PCS

Hardware ③ x2PCS






3

Part ❷ x1PC

Hardware ⑩ x1PC

Accessory A2 x1PC

Accessory A4 x1PC



ASSEMBLY INSTRUCTIONS

4


Part **D** x1PC

Part **E** x1PC

Hardware **⑤** x3PCS

Accessory **A4** x1PC

Please ensure panel (#D) and panel (#F) are oriented correctly as shown in the diagrams.




5

Part **A** x1PC

Part **F** x1PC


Hardware **⑤** x2PCS

Accessory **A4** x1PC





ASSEMBLY INSTRUCTIONS

6



Part **G** x1PC

Hardware **②** x2PCS




7

Part **H** x1PC

Part **I** x1PC

Hardware **②** x4PCS





ASSEMBLY INSTRUCTIONS

8

Part **J** x1PC

Part **K** x1PC

Hardware **②** x2PCS




9

Part **B** x1PC

Hardware **⑤** x10PCS

Accessory **A4** x1PC




ASSEMBLY INSTRUCTIONS

10

Part **U** x2PCS

Hardware **10** x4PCS

Accessory **A4** x1PC



11


Part **S** x1PC

Part **T** x1PC

Part **V** x1PC

Hardware **9** x6PCS


Accessory **A4** x1PC



ASSEMBLY INSTRUCTIONS

12


Hardware ⑧ x8PCS



13

Hardware ⑧ x4PCS

Accessory A3 x5PCS






ASSEMBLY INSTRUCTIONS

14

Part **L** x4PCS

Hardware **⑦** x16PCS



X16

15

Part **M** x1PC

Part **N** x1PC

Part **O** x1PC





Part **P** x1PC

Part **Q** x1PC

Part **R** x1PC

Hardware **②** x4PCS



Hardware **④** x4PCS



ASSEMBLY INSTRUCTIONS


16

Hardware ⑥ x2PCS






17

Accessory ①A1 x5PCS



18

Accessory **A5** x6PCS







X6

19

Accessory **A7** x1PC

Accessory **A8** x1PC

Accessory **A9** x1SET



For safety, please secure unit onto wall by using wall mounted straps provided. Refer to page 19 on wall mounting guide.

20

ASSEMBLY COMPLETED




Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.




ASSEMBLY INSTRUCTIONS

Wall Mounting and Fixing



EXPANSION WALL ANCHOR

Our provided expansion wall anchors are only suitable for masonry walls, such as drywall, plaster or concrete, and are best for holding lightweight items or for anti-tip prevention. If you are unsure of the correct wall anchor to use with the product, please request professional guidance. Liability for product damage or failure due to using the incorrect anchors will fall on the installer.




CHECK BEFORE PROCEEDING


Prior to drilling or hammering, please check for wires or pipes. We recommend using a stud finder to locate a stud, which will offer more appropriate resistance and hold more weight.

QUICK TIPS


1. If unsure of the proper size, always choose a larger screw and wall anchor.




2. Match the drill bit to the wall anchor and hole size.



3. Only drill horizontally. Do not force the drill or enlarge the hole for the wall anchor.



4. Take extra care when drilling into high walls or ceramic tiles. Wall anchors should be a tight fit for the hole. Never use wall anchors in ceilings.



MAINTENANCE

Yearly
Check

We recommend a yearly check to see if the wall anchor or screw has loosened. If so, please remove the existing wall anchor and screw, and use a new anchor.