


Assembly Instructions

Caution: You must read this before you proceed

Bench



Part List





Label	Picture	Description	QTY
A		Leg	2
B		Seat	1






Hardware

Label	Picture	Description	QTY
①		Bolt (M6*20mm)	3

②		Bolt (M6*25mm)	5
③		Allen Key	1


Assembly Preparation

Before Beginning Assembly:	  *3   *5
----------------------------	--

-  Read instructions, cover to cover-
-  Have 2 adults on hand for assembly-
-  Do not assemble on flooring or carpet-
-  Assemble on a clean non-marring surface (packing foam)-
-  Save all packaging until finished-


Assembly Steps

Overview



This Bench has multiple parts and may require up to 20 minutes to assemble. To give you an overview of the bench parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1




Open the carton and place all the parts onto a clean, non-marring surface.
Insert Leg(A) into Seat(B) as pictured above.

1.1) Attach Leg(A) to Seat(B) using Bolts(2) with Allen Key(3) as shown above.

1.2) Attach Leg(A) to Seat(B) using Bolts(1) with Allen Key(3).

Do not fully tighten the Bolts.

Step 2




Insert Leg(A) into Seat(B) as pictured above.

2.1) Attach Leg(A) to Seat(B) using Bolts(2) with Allen Key(3) as shown above.

2.2) Attach Leg(A) to Seat(B) using Bolts(1) with Allen Key(3).

Do not fully tighten the Bolts.

Step 3



Stand the Bench up.

Place the Bench on a **LEVEL SURFACE**.

Inspect it and make sure all parts are adequately connected.

Gently and carefully sit onto the Bench

This will help to align all parts at all joints.

Then get off the Bench, and in a sequential manner, proceed to tighten all Bolts.

When tightening the Bolts, tighten sequentially.

DO NOT tighten any Bolt fully and then move on to the next one.

This may cause the frame to warp.













If there are still wobbles, loosen the Bolts and execute this same process.

Note: This step is done best with the assistance of a second adult.

Your Bench is ready for use.


This Bench can only be used on a flat, level surface.

Care & Maintenance

-   ● Do not put hot items directly on furniture surface
-   ● Do not clean furniture with harsh cleansers or polish.
-   ● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
-   ● Children should not climb or jump on the furniture.
-   ● Do not write on furniture without a padded barrier to protect the surface.
-   ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



- Not for commercial use. For residential use only .



- Stains may be removed with mild soap solution and damp cloth.



- Keep away from sources of ignition.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.