



*ASSEMBLY INSTRUCTIONS*  
**COASTER FINE FURNITURE**



*Fine Furniture for every stage of life*

**CABINET**

**951766**

ITEM : 951766



## ASSEMBLY INSTRUCTIONS


### ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

10 MINUTES

## PARTS IDENTIFICATION

## HARDWARE

A TABLE TOP



1PC

1

WASHER



4PC

B BASE




1PC


ITEM : 951766


ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2





Note: Dimension tolerance  $\pm 5\%$

