Thank You for purchasing this Quality product, it has been engineered for easy of assembly yet constructed for durability. Please take the time to read and follow the instruction while assembling.

36" x 60" Leg Table Oak

- Model: 17 - T 3660

## Notes

- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials including staples & packing straps before you start to assemble.

## Care And Maintenance

- The Touch of a soft cloth is all the maintenance your wood pieces will ever need.
- Never use harsh chemicals or abrasive cleaner as they could mark or destroy finish.




## Important Notes


- Keep all hardware parts out of reach of children.
- \* Must tighten screws periodically. With use screws will become loose.Check tightness of all screws every 6-8 weeks.
- Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatedly.



Step 1 Turn the under side of the Table Top over and place it on a clean and smooth surface such as rug or carpet to avoid the Table Top from being scratch.



Fix the Leg to the corner of the Apron with Flat Washer, Spring Step 2 Washer and Hexagon Nut, Using the Spanner to tighten it.



List of Part



Table Top



List of hardware (a) (b)









Flat Washer 8

8

8

1

(d)