

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.






Remove wooden furniture from standing water. Dust regularly with small brush or vacuum







Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Long leg		2X
B	Short leg		2X
C	Bracing the lower leg		1X
D	Shoulder frame		1X
E	Floor		4X

PIECE	DESCRIPTION	PICTURE	QUANTITY
F	Screw	 M6x50	6X
G	Bolt	 M6x30	2X
H	Bolt	 M6x18	8X
I	Nut	 M6x15	2X
J	Washer	 M6.5/24X1.5	2X
K	Allen key	 LG4	2X

 **SAFAVIEH**
O U T D O O R

Weight Capacity : 600 Ibs


Warning : Do not stand on chair

Warning : Do not over torque bolts / screws



Model# PAT7063

Product Dimensions: 17.63" W x 23.62" D x 67.32" H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key

1



2



Step 1

Attach Long leg (A) to Short leg (B) ,use Bolt (G) ,Washer (J) and Nut (I) tighten with allen key (K).

Step 2

Attach Floor (E), Shoulder frame (D), Bracing the lower leg (C) to Long leg (A) use Bolt (G) and tighten with allen key (K).

And finally use Screw (F) and tighten with allen key (K). Complete product.