

CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

NOTICE



- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening



Model# DSK2209

Product Dimensions: 43.3"W×21.7"D×29.5"H

Part List and Hardware List



Ax2 	Bx8 	Cx6  6x95mm	Dx2  6x45mm	Ex2  6x20mm	Fx4  6x12mm	Gx12 	Hx2 
Ix2 	Jx6  4x35mm	Kx6 	Lx6 	Mx10  4x25mm	Nx4  5x50mm	Ox1 	


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.


If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 60 minutes.


1




2




3




4




5




6




7




8




9




10




11



12



13



14

