



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

708057
END TABLE

REVISION 0 : 09/27/2017
REVISION 1 : 05/17/2019
REVISION 2 : 11/11/2022

PAGE 1 OF 6

COASTERFURNITURE.COM

ITEM: 708057

ASSEMBLY INSTRUCTIONS

COASTER
FINE FURNITURE

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME **30 MINUTES**


PARTS IDENTIFICATION

A TOP GLASS



1PC

B SIDE FRAME



4PCS

HARDWARE IDENTIFICATION

1 SCREW
(3/16" x 12mm GD)



4PCS

4 LEVELER
(1/4" x 12mm BLK)



4PCS

2 BOLT
(1/4" x 12mm GD)



4PCS

5 ALLEN WRENCH
(4mm)



1PC

3 SUCTION CUP
(Ø8mm)




4PCS

ITEM: 708057
ASSEMBLY INSTRUCTIONS


COASTER[®]
FINE FURNITURE

STEP 1

Do not tighten until each step is completed or instructed.




STEP 2




ITEM: 708057
ASSEMBLY INSTRUCTIONS

COASTER®
FINE FURNITURE

STEP 3




STEP 4




ITEM: 708057
ASSEMBLY INSTRUCTIONS

COASTER[®]
FINE FURNITURE


STEP 5



STEP 6



COMPLETE




ITEM:708057
ASSEMBLY INSTRUCTIONS



Product Size : 597 DIA X 597 H (MM)

Product Size : 23 $\frac{1}{2}$ " DIA X 23 $\frac{1}{2}$ "



Note : Dimension tolerance $\pm 5\%$