

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

110292 Side Chair

REVISION 0 : 08/31/2020 REVISION 1 : 10/23/2025 PAGE 1 OF 4

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

AN	BACK FRAME	1PC
BN	SEAT CUSHION WITH FRAME	1PC
CN	FRONT LEG	2PCS

HARDWARE IDENTIFICATION

1	LONG BOLT (Ø1/4 x 13 x 75mm - RBW)		4PCS
2	MEDIUM BOLT (Ø1/4 x 13 x 63mm - RBW)		4PCS
3	SHORT BOLT (Ø1/4 x 13 x 38mm - RBW)		2PCS
4	LOCK WASHER (Ø1/4 x 10 x 1.1mm - RBW)	0	10PCS
5	FLAT WASHER (Ø1/4 x 22 x 2mm - RBW)		10PCS
6	ALLEN WRENCH (4 x 60mm - RBW)		1PC

NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


COASTER

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




COASTER

ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4 COMPLETE









Note: Dimension tolerance ±5%