ITEM CODE: 5164-02-3A

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all part is complete, before you assemble. Place all wooden furniture part on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

## CAUTIONS:

- 1. Do not FULLY-TIGHTEN the nut or nut bolt until all nut or bolt is ready assembled.
- 2. Do not OVER-TIGHTEN the nut or nut bolt to avoid causing damages to the thread.
- 3. Keep all hardware part out of reach of children.

PART LIST			HARDWARE LIST			
ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION		QTY
1	CHAIR BACK	1 PC	Α	JCBC SCREW M6 x 35MM		2 PCS
2	FRONT LEG	2 PCS	В	JCBC SCREW M6 x 60MM		4 PCS
3	SEAT FRAME	1 PC	С	JCBC SCREW M6 x 80MM		4 PCS
			D	SPRING WASHER 1/4"	9	10 PCS
			Е	FLAT WASHER 1/4"	0	10 PCS
			F	ALLEN KEY M4 (BALL SHAPE)		1 PC

