TOOLS REQUIRED



Allen Wrench

(Included)



Phillips Screwdriver

(Not Included)



3 - People Recommended

ASSEMBLY RATING



EASY → DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



Are you missing anything?	Check out our Quick Tips!	
Double-check all parts, hardware and accessories listed on Page 6 are accounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now an then!	
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.	

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

QUEEN / FULL BED



- Please keep instructions for future reference.
- · Check the quantity and irregularity of parts and hardware before you start.



PARTS





Headboard






Wings(L&R)



1set



Slat (13pcs)



1pc



Footboard



(#5) 2pcs



HB Foot(L&R)

4pcs



Support leg $\emptyset_{\overline{16}}^{\underline{5}}$ " 225X30X30mm



2pcs



Side Rail



(#6) 2pcs





FB Foot(L&R)





1pc

Support Rail

HARDWARE



1pc



#B 4pcs





Allen Key

Bolt Ø5/16"X1-1/2"



Bolt Ø5/16"X2"

8pcs



2pcs



10pcs





Bolt Ø5/16"X2-1/2"

Bolt Ø5/16"X4"





10pcs



(#H) 20pcs



Ø5/16"X19MM






Flat Washer Ø5/16"X22MM

Spring Washer

Screw #8X38MM

Carton	Disignation	Part		Hardware	
	Headboard	#1			#A x 1pc
				9	#B x 4pcs
	Wings(L&R)	#4		(1)	#C x 8pcs
	HB feet(L&R)	#5		0	#D x 6pcs
			4 4	(1)	#E x 2pcs
	FB feet	#6		@	#F x 10pcs
	Slat (13pcs)	#7			#Gx 10pcs #Hx 20pcs
	Support leg	#8		#	#I x 26pcs
	Footboard	#2			
	Side Rail	#3			
	Support Rail	#9			


Exploded View




1

Part#1 x1pc

Remove HB legs (#5) from the back compartment of the headboard (#1).






Align wings (#4R/L) to the headboard (#1), then secure by using bolts (#C,E) with washers (#H,G).

3

Part #4 x2pcs
Hardware #A x1pc
Hardware #C x4pcs
Hardware #D x2pcs
Hardware #E x2pcs

Hardware #G x6pcs

Hardware #H) x6pcs



4

Part(#2) x1pc


Part (#6) x2pcs


Hardware(#A) x1pc


Hardware #D x2pcs


Hardware #F)x2pcs

Hardware(#H)x2pcs











ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.