ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED



(Included)



2 - People Recommended

ASSEMBLY RATING



EASY -→ DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 20-06-12



Are you missing anything? Double-check all parts, hardware and		Check out our Quick Tips! We recommend reviewing the pre-assembly
accessories listed on Page 6 are accounted for.		handouts. Even experts need a refresher now and then!
	1 1	
Should we send any replacements?		Prep Time!

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

SIDE CHAIR



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS





Back Frame





Seat Cushion





Leg

HARDWARE





Bolt ϕ 5/16" x 90mm





Lock Washer Ø5/16"

(#B) 4pcs x2



Bolt *\$\phi\$*5/16" x 55mm





Flat Washer Ø5/16"

#C) 3pcs x2




Bolt ϕ 5/16" x 50mm





Allen Wrench 5mm

Exploded View



ASSEMBLY INSTRUCTIONS

1


Part #1 x1pc

Part #2 x1pc

Hardware #A x4pcs

Hardware #D x4pcs

Hardware #E x4pcs



2

Hardware #C x3pcs

Hardware #D x3pcs

Hardware (#E) x3pcs

#F #C #D #E

ASSEMBLY INSTRUCTIONS

3


Part #3 x2pcs

Hardware (#B) x4pcs


Hardware (#D) x4pcs

Hardware #E x4pcs

Align legs (#3) to the seat, then secure by using bolts (#B) with washers (#D,E).



4



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.