

**Assembly Instruction**

**DOUBLE GLIDER RECLINING LOVE  
SEAT WITH CONSOLE**


**ITEM NO.: 194S9636-2/194S9636CC-2**




The parts stored in the bottom of the sofa, please take out for assembly

**NOTE:** Do not use power tools for assembly. Power tools increase the risk of over tightening which leads to splitting or cracking the wood.


**COMPONENT LIST (LOVE SEAT)**

NO.	DRAWING	QTY	DESCRIPTION
A		1	SEAT
B		1	LEFT BACK REST
C		1	RIGHT BACK REST
D		1	CONSOLE BACK REST
E		1	LEFT EAR
F		1	RIGHT EAR


**STEP# 1**



**STEP# 2**



## STEP# 4



### **Care Instruction for Fabric Furniture.**

In order to maintain the original appearance of your fabric furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and/or exposure to heating and air conditioning outlets will fade/damage fabrics.
- Vacuum or wipe with a soft brush to remove dust.



**For items use on wooden floor, hard surfaces or carpets, it is recommended to install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.**